

Technology for Vacuum Systems

Instructions for use

Part I of II



Part I: Safety information -Technical data -Use and operation PC 3001 VARIO^{pro}
PC 3001 TE VARIO^{pro}
PC 3001 VARIO^{pro} IK
PC 3001 VARIO^{pro} EK Peltronic

Chemistry pumping unit with speed control

Dear customer,

Your VACUUBRAND diaphragm pumps are designed to provide you with many years of trouble-free service with optimal performance. Our many years of practical experience allow us to provide a wealth of application and safety information. Please read these instructions for use before the initial operation of your pump.

VACUUBRAND diaphragm pumps combine our many years of experience in design, construction and practical operation, with the latest developments in material and manufacturing technology.

Our quality maxim is the "zero defect" principle:

Every diaphragm pump, before leaving our factory, is tested intensively, including an endurance run of 14 hours. Any faults, even those which occur rarely, are identified and can be eliminated immediately.

After completion of the endurance run, every pump is tested, and must achieve specifications before shipment.

We are committed to providing our customers only pumps that meet this high quality standard.

While our pumps cannot eliminate all of your work, we design, manufacture and test them to ensure that they will be an effective and trouble-free tool to assist you in that work.

Yours, VACUUBRAND GMBH + CO KG

After sales service:

Contact your local dealer or call +49 9342 808-5500.

Trademark index:

VACUU•LAN® (US-Reg.No 3,704,401), VACUU•BUS®, VACUU•CONTROL®, Peltronic®, VARIO® (US-Reg.No 3,833,788), VACUUBRAND® (US-Reg.No 3,733,388) and also the shown company logos are registered trademarks of VACUUBRAND GMBH + CO KG in Germany and/or other countries.

DE

Achtung: Die vorliegende Betriebsanleitung ist nicht in allen EU-Sprachen verfügbar. Der Anwender darf die beschriebenen Geräte nur dann in Betrieb nehmen, wenn er die vorliegende Anleitung versteht oder eine fachlich korrekte Übersetzung der vollständigen Anleitung vorliegen hat. Die Betriebsanleitung muss vor Inbetriebnahme der Geräte vollständig gelesen und verstanden werden, und alle geforderten Maßnahmen müssen eingehalten werden.

ΕN

Attention: This manual is not available in all languages of the EU. The user must not operate the device if he does not understand this manual. In this case a technically correct translation of the complete manual has to be available. The manual must be completely read and understood before operation of the device and all required measures must be applied. Safety instructions for vacuum equipment"

FR

Attention: Le mode d'emploi présent n'est pas disponible dans toutes les langues d'Union Européenne. L'utilisateur ne doit mettre le dispositif en marche que s'il comprend le mode d'emploi présent ou si une traduction complète et correcte du mode d'emploi est sous ses yeux. Le dispositif ne doit pas être mis en marche avant que le mode d'emploi ait été lu et compris complètement et seulement si le mode d'emploi est observé et tous les mesures demandées sont prises.

«Avis de sécurité pour des dispositifs à vide»

BG

Внимание: Тези инструкции не са преведени на всички езици от ЕО. Потребителят не бива да работи с уреда, ако не разбира инструкциите за ползване. В този случай е необходимо да бъде предоставен пълен технически превод на инструкциите за ползване. Преди работа с уреда е задължително потребителят да прочете изцяло инструкциите за работа.

№ "Указания за безопасност за вакуумни уреди"

CN

注意:该操作手册不提供所有的语言版本。操作者在没有理解手册之前,不能操作 该设备。在这种情况下,需要有一个整个操作手册技术上正确的翻译。在操作该设 备前,必须完全阅读并理解该操作手册,必须实施所有需要的测量。

5℃ 真空设备的安全信息

CZ

Upozornění :Tento návod k použití není k dispozici ve všech jazycích Evropské unie. Uživatel není oprávněn požít přístroj pokud nerozumí tomuto návodu. V takovém případě je nutno zajistit technicky korektní překlad manuálu do češtiny. Návod musí být uživatelem prostudován a uživatel mu musí plně porozumět před tím než začne přístroj používat. Uživatel musí dodržet všechna příslušná a požadovaná opatření. ** Bezpečnostní upozornění pro vakuové přístroje*.

DA

Bemærk: Denne manual foreligger ikke på alle EU sprog. Brugeren må ikke betjene apparatet hvis manualen ikke er forstået. I det tilfælde skal en teknisk korrekt oversættelse af hele manual stilles til rådighed. Manual skal være gennemlæst og forstået før apparatet betjenes og alle nødvendige forholdsregler skal tages.

»Sikkerhedsregler for vakuumudstyr«

EE

Tähelepanu! Käesolev kasutusjuhend ei ole kõigis EL keeltes saadaval. Kasutaja ei tohi seadet käsitseda, kui ta ei saa kasutusjuhendist aru. Sel juhul peab saadaval olema kogu kasutusjuhendi tehniliselt korrektne tõlge. Enne seadme kasutamist tuleb kogu juhend läbi lugeda, see peab olema arusaadav ning kõik nõutud meetmed peavad olema rakendatud. Ohutusnõuded vaakumseadmetele"

ES

Atención: Este manual no está disponible en todos los idiomas de UE. El usuario no debe manejar el instrumento si no entiende este manual. En este caso se debe disponer de una traducción técnicamente correcta del manual completo. El manual debe ser leído y entendido completamente y deben aplicarse todas las medidas de seguridad antes de manejar el instrumento. Notas sobre la seguridad para equipos de vacío"

FI

Huomio: Tämä käyttöohje ei ole saatavilla kaikilla EU: n kielillä. Käyttäjä ei saa käyttää laitetta, jos hän ei ymmärrä tätä ohjekirjaa. Tässä tapauksessa on saatavilla oltava teknisesti oikein tehty ja täydellinen ohjekirjan käännös. Ennen laitteen käyttöä on ohjekirja luettava ja ymmärrettävä kokonaan sekä suoritettava kaikki tarvittavat valmistelut ja muut toimenpiteet. "Vakuumilaitteen turvallisuustiedot"

GR

Προσοχή! : Οι οδηγίες αυτές δεν είναι διαθέσιμες σε όλες τις γλώσσες της Ευρωπαϊκής Ένωσης. Ο χρήστης δεν πρέπει να θέσει σε λειτουργία την συσκευή αν δεν κατανοήσει πλήρως τις οδηγίες αυτές. Σε τέτοια περίπτωση ο χρήστης πρέπει να προμηθευτεί ακριβή μετάφραση του βιβλίου οδηγιών. Ο χρήστης πρέπει να διαβάσει και να κατανοήσει πλήρως τις οδηγίες χρήσης και να λάβει όλα τα απαραίτητα μέτρα πριν θέσει σε λειτουργία την συσκευή. (ΕΝΤΟΝΟΣ) "Υποδείξεις ασφάλειας για αντλίες κενού"

HR

Pažnja:ove upute ne postoje na svim jezicima Europske Unije. Korisnik nemora raditi sa aparatom ako ne razumije ove upute.U tom slucaju tehnicki ispravni prijevod cijelih uputstava mora biti na raspolaganju. Uputstva moraju biti cijela procitana i razumljiva prije rada sa aparatom i sve zahtijevane mjere moraju biti primjenjene.

"Sigurnosne napomene za vakuumske uređaje"

HU

Figyelem! Ez a kezelési utasítás nem áll rendelkezésre az EU összes nyelvén. Ha a felhasználó nem érti jelen használati utasítás szövegét, nem üzemeltetheti a készüléket. Ez esetben a teljes gépkönyv fordításáról gondoskodni kell. Üzembe helyezés előtt a kezelőnek végig kell olvasnia, meg kell értenie azt, továbbá az üzemeltetéshez szükséges összes mérést el kell végeznie. A vákuum-készülékekkel kapcsolatos biztonsági tudnivalók"

IT

Attenzione: Questo manuale non è disponibile in tutte le lingue della Comunità Europea (CE). L'utilizzatore non deve operare con lo strumento se non comprende questo manuale. In questo caso deve essere resa disponibile una traduzione tecnicamente corretta del manuale completo. Il manuale deve essere completamente letto e compreso prima di operare con lo strumento e devono essere applicati tutti gli accorgimenti richiesti. Si l'Istruzioni di sicurezza per apparecchi a vuoto"

JP

注意:この取扱説明書はすべての言語で利用可能ではありません。 もしこの取扱説明書を理解できないならば、ユーザーは装置を操作してはなりません。 この場合、技術的に正しい翻訳がなされた完全なマニュアルを用意しなければなりません。 装置を作動する前にマニュアルを完全に読み、そして理解されなくてはなりません。そして、すべての要求される対策を講じなければなりません。

∞ 真空装置を安全に取り扱うために

KR

주의: 이 매뉴얼은 모든 언어로 번역되지는 않습니다. 만약 이 매뉴얼의 내용을 충분히 인지하지 못했다면 기기를 작동하지 마십시오. 매뉴얼의 내용을 기술적으로 정확하게 번역한 경우에 이용하십시오. 기기를 사용하기 전에 이 매뉴얼을 충분히 읽고이해하고 모든 요구되는 사항들을 적용해야 합니다.

○ 진공 장비에 대한 안전 정보

LT

Dėmesio: šis vadovas nėra pateikiamas visomis ES kalbomis. Naudotojui draudžiama eksploatuoti įtaisą, jeigu jis nesupranta šio vadovo. Tokiu atveju reikia turėti viso vadovo techniškai taisyklingą vertimą. Vadovą būtina visą perskaityti ir suprasti pateikiamas instrukcijas prieš pradedant eksploatuoti įtaisą, bei imtis visų reikiamų priemonių. Š "Vakuuminės įrangos saugos informacija"

LV

Uzmanību: Lietotāja instrukcija nav pieejama visās ES valodās. Lietotājs nedrīkst lietot iekārtu, ja viņš nesaprot lietotāja instrukcijā rakstīto. Šādā gadījumā, ir nepieciešams nodrošināt tehniski pareizu visas lietotāja instrukcijas tulkojumu. Pirms sākt lietot iekārtu, un, lai izpildītu visas nepieciešamās prasības, iekārtas lietotāja instrukcija ir pilnībā jāizlasa un jāsaprot.

NL

Attentie: Deze gebruiksaanwijzing is niet in alle talen van de EU verkrijgbaar. De gebruiker moet niet met dit apparaat gaan werken als voor hem/haar de gebruiksaanwijzing niet voldoende duidelijk is. Bij gebruik van deze apparatuur is het noodzakelijk een technisch correcte vertaling van de complete gebruiksaanwijzing te hebben. Voor het in gebruik nemen van het apparaat moet de gebruiksaanwijzing volledig gelezen en duidelijk zijn en dienen alle benodigde maatregelen te zijn genomen. Veiligheidsvoorschriften voor vacuümapparaten

PL

Uwaga!! Ta instrukcja nie jest dostępna we wszystkich językach Unii Europejskiej. Użytkownik nie może rozpocząć pracy z urządzeniem dopóki nie przeczytał instrukcji i nie jest pewien wszystkich informacji w niej zawartych. Instrukcja musi byc w całości przeczytana i zrozumiana przed podjęciem pracy z urządzeniem oraz należy podjąć wszystkie niezbędne kroki związane z prawidłowym uzytkowaniem.

"Wskazówki bezpieczeństwa do urządzeń próżniowych"

PT

Atenção: Este manual não está disponível em todas as línguas da UE. O usuário não deve utilizar o dispositivo, se não entender este manual. Neste caso, uma tradução tecnicamente correta do manual completo tem de estar disponível. O manual deve ser lido e entendido completamente antes da utilização do equipamento e todas as medidas necessárias devem ser aplicadas. "Informação de Segurança para Equipamento que funciona a Vácuo"

RO

Atentie: Acest manual nu este disponibil in toate limbile EU. Utilizatorul nu trebuie sa lucreze cu aparatul daca daca nu intelege manualul. Astfel, va fi disponibile o traducere corecta si completa a manualului. Manualul trebuie citit si inteles in intregime inainte de a lucra cu aparatul si a luat toate masurile care se impun.

"Instrucțiuni de siguranță pentru aparatele de vidare"

RU

Внимание: Эта инструкция по эксплуатации не имеется на всех языках. Потребителю не дозволенно эксплуатировать данный прибор, если он не понимает эту инструкцию. В этом случае нужен технически правильный перевод полной инструкции. Прежде чем использовать этот прибор,

необходимо полностью прочитать и понять эту инструкцию и принять все необходимые меры. Эту зазания по технике безопасности при работе с вакуумными устройствами"

SE

Varning: Denna instruktion är inte tillgänglig på alla språk inom EU. Användaren får inte starta utrustningen om hon/han inte förstår denna instruktion. Om så är fallet måste en tekniskt korrekt instruktion göras tillgänglig. Instruktionen måste läsas och förstås helt före utrustningen tas i drift och nödvändiga åtgärder göres.

"Säkerhetsinformation för vakuumutrustning"

SI

Pozor: Ta navodila niso na voljo v vseh jezikih EU. Uporabnik ne sme upravljati z napravo, če ne razume teh navodil. V primeru nerazumljivosti mora biti na voljo tehnično pravilen prevod. Navodila se morajo prebrati in razumeti pred uporaba naprave, opravljene pa moraja biti tudi vse potrebne meritve.

"Varnostni nasveti za vakuumske naprave"

SK

Upozornenie: Tento manuál nie je k dispozícii vo všetkých jazykoch EÚ. Užívateľ nesmie obsluhovať zariadenie, pokiaľ nerozumie tomuto manuálu. V takomto prípade musí byť k dispozícii technicky správny preklad celého manuálu. Pred obsluhou zariadenia je potrebné si prečítať celý manuál a porozumieť mu, a musia byť prijaté všetky opatrenia.

TR


Dikkat: Bu kullanım kitabı, tüm dillerde mevcut değildir. Kullanıcı, bu kullanım kitabının anlayamadıysa cihazı çalıştırmamalıdır. Bu durumda, komple kullanım kitabının, teknik olarak düzgün çevirisinin bulunması gerekir. Cihazın çalıştırılmasından önce kullanım kitabının komple okunması ve anlaşılması ve tüm gerekli ölçümlerin uygulanması gerekir. "Vakumlu cihazlar için güvenlik uyarıları"

Reset / Language selection


1 switch off




2 press both **↓ ↓**



3 turn



4 press **↓**



Contents

Part I	1
Reset / Language selection	8
Safety information!	
Important information!	
General information	
Intended use	
Setting up and installing the equipment	14
Ambient conditions	
Operating conditions	17
Safety during operation	19
Maintenance and repair	
(Ex) Important information: Equipment marking (ATEX)	25
Technical data	
General technical data valid for all pumping units	
Gas inlet temperatures	
Wetted parts	
Abbreviations	
Pump parts	
Use and operation	
Installing a pump in a vacuum system	
Notes regarding the (dry) ice condenser	
Notes concerning the operation of the inlet condenser IK	45
Notes concerning the operation of the	40
Peltronic emission condenser	
Notes concerning the operation of pumping units with silencer During operation	
Important notes regarding the use of gas ballast	
Important notes regarding the use of gas ballast Important notes concerning the operation of the	40
exhaust waste vapor condenser	49
Shutdown & storage	
CVC 3000 Vacuum controller	
Menu guide	
Pump down function	
Vac Control function	
Auto mode	
Program function	
Application example	

VACUULAN function	69
Application examples	71
Vacuum for filtration and suction	
Vacuum for gel dryer,	
drying chambers and vacuum concentrators	72
Vacuum for distillation and evaporation (e.g., rotary evaporator)	
Vacuum for VACUU•LAN networks	
Configuration	75
Dort II	77
Part II	
Readjustment of CVC 3000	
Calibration in the factory	
Cleaning the pressure transducer	
Interface parameters	
Setting of the interface	
Read commands "CVC 2000"	
Write commands "CVC 2000"	
Read commands "CVC 3000"	
Write commands "CVC 3000"	
Accessories	
Troubleshooting	
Replacing diaphragms and valves	
Cleaning and inspecting the pump heads	101
Disassembling the housing cover	400
at the side of the emission condenser	
Replacing the diaphragm	105
Assembling the housing cover at the side of the emission condenser	100
Disassembling the housing cover	100
at the side of the ON/OFF switch	108
Assembling the housing cover at the side of the ON/OFF switch	
Assembling the fittings	
Cleaning and replacing components	
Repair - Maintenance - Return - Calibration	
Warranty	
EC Declaration of Conformity of the Machinery	. 117 110

Safety information!

Important information!

AWARNING

- Keep this manual complete and accessible to personnel at all times!
- Read this manual carefully before installing or operating the equipment. Observe the instructions contained in this manual.

PC 3001 VARIO^{pro} with Peltronic emission condenser: Read the manual of the emission condenser Peltronic as well and observe likewise the instructions contained in that manual.

Do not modify the equipment without authorization.

NOTICE

This manual is an integral part of the equipment described therein. It describes the safe and proper use of the vacuum pump. The manual consists of two parts. Make operating personnel aware of dangers arising from the pump and the pumped substances. VACUUBRAND disclaims any liability for inappropri-

ate use of these pumps and for damage from failure to follow instructions contained in this manual.

This manual is only to be used and distributed in its complete and original form. It is strictly the users' responsibility to check carefully the validity of this manual with respect to his product.

Manual-no.: 999166 / 07/24/2017

The following signal word panels and safety symbols are used throughout this manual:



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury and death.



■ DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



warning indicates a hazardous situation which, if not avoided, <u>could</u> result in death or serious injury.



• CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



NOTICE is used to address practices not related to personal injury.



Caution! Hot surface!



Disconnect equipment from AC power.



Dispose of electronic equipment according to regulations.



This product has been tested to the requirements of CAN/CSA-C22.2 No. 61010-1, second edition, including amendment 1, or a later version of the same standard incorporating the same level of testing requirements.

Formatting used in this manual:

Note: The signal word panels in all sections of this manual always refer to all paragraphs of the same format (► / 🖾 / • / plain text) following each signal word panel.

The document "Safety information for vacuum equipment" is part of this manual! Read the "Safety information for vacuum equipment" and observe the instructions contained therein!

General information

NOTICE

Remove all packing material from the packing box. Remove the product from its packing box and retain all packaging until the equipment is inspected and tested. Remove the protective caps from the inlet and outlet ports and retain for future use. Inspect the equipment promptly and carefully.

If the equipment is damaged, notify the supplier and the carrier in writing within three days. Retain all packing material for inspection. State the item number of the product together with the order number and the supplier's invoice number. Failure to check and give notice of damage will void any and all warranty claims for those deficiencies.

Replace the protective caps if the equipment is not used immediately. Store the equipment in dry and non-corrosive conditions (see also "Technical data", pg. 27).

AWARNING

■ Do not use any damaged equipment.



Use the mounted handle when moving the pumping unit.

Intended use



- Do not use the pump or any system parts on humans or animals.
- Ensure that the individual components are only connected, combined and operated according to their design and as indicated in the instructions for use. Use only **original manufacturer's spare parts and accessories**. Otherwise the safety and performance of the equipment, as well as the electromagnetic compatibility of the equipment might be reduced.

The CE mark or the cTÜVus mark may be voided if not using original manufacturer's spare parts.

- Comply with all notes on correct vacuum and electrical connections; see section "Use and operation", pg. 38.
- Do not use the pump to generate pressure.
- The pumps are designed for **ambient temperatures** during operation between +50°F and +104°F (+10°C and +40°C). Periodically check maximum temperatures if installing the pump in a cabinet or a housing. Make sure ventilation is adequate to maintain recommended operating temperature. Install an external automatic ventilation system if necessary. If pumping hot process gases, make sure that the maximum permitted gas inlet temperature is not exceeded. The maximum permitted gas inlet temperature depends on several parameters like inlet pressure and ambient temperature (see "Technical data", pg. 27).
- Particles and dust must not enter the pump.
- Do not pump liquids.



 Ensure that the pump, and any accessories in the flow path are chemically resistant to the pumped substances prior to operation.

NOTICE

Use the equipment **only as intended**, that is, for generation, measurement, and control of vacuum in vessels designed for that purpose. Any other use will automatically invalidate all warranty and liability claims. Remain aware of safety and risks.

Setting up and installing the equipment



➡ Equipment must be connected only to a suitable electrical supply and a suitable ground point. As such, the plug must be plugged into an outlet that is properly grounded. Failure to connect the motor to ground may result in deadly electrical shock. The supply cable may be fitted with a molded European IEC plug or a plug suitable for your local electrical supply. The cable contains wires color coded as follows: green or green and yellow: ground; blue or white: neutral; brown or black: hot.

AWARNING

- Due to the high compression ratio, the pump may generate overpressure at the outlet. Check pressure compatibility with system components (e.g., exhaust pipeline or exhaust valve) at the outlet.
- Do not permit any **uncontrolled pressurizing**. Make sure that the exhaust pipeline cannot become blocked. If there is an exhaust isolation valve, make sure that you cannot operate the equipment with the valve closed to avoid a **risk of bursting!**
- Maximum permissible pressure at the pressure transducer: 21.8 psi (1.5 bar) absolute.
- Keep the electrical power cord away from heated surfaces.

ACAUTION

- Provide a firm, level platform for the equipment. Check that the system which you are going to evacuate is mechanically stable. Check that all fittings are secure. Ensure a stable position of the pump without any mechanical contact other than the pump feet.
- Comply with maximum permissible pressures at inlet and outlet and with maximum permissible pressure differences between inlet and outlet. See section "Technical data", pg. 27. Do not operate the pump with overpressure at the inlet.
- Avoid overpressure of more than 17.5 psi absolute (1.2 bar absolute) in the event that inert gas is connected to the pump, to the gas ballast or to a venting valve.
- Note: Flexible elements will shrink when evacuated.
- Connect hoses gas tight at inlet and outlet of the pump.

- Ensure that no foreign objects can be drawn into the pump.
- Check the power source and the pump's rating plate to be sure that the power source and the equipment match in voltage, phase, and frequency.
- Ensure that the coolant outlet pipe is always free and that it cannot get blocked. If installing an optional coolant valve, it must always be in the supply line of the exhaust waste vapor condenser.

NOTICE

Make sure ventilation is adequate to maintain recommended operating temperature. Keep a minimum distance of 2 in (5 cm) between the cooling fan and surrounding items (e.g., housing, walls, etc.), or else install an external automatic ventilation system. Clean ventilation slots if necessary to avoid a reduction of ventilation.

Do not place the pumping unit on soft surfaces (e.g., rubber foam) during operation. This may reduce or block the electronics' air supply. Do not cover the pumping unit.

Use only hoses at the inlet and outlet of the pump with an inner diameter at least as large as the diameter of the pump's tubing (to avoid overpressure at the outlet, and reduction of pumping speed at the inlet).

Allow the equipment to equilibrate to ambient temperature if you bring it from cold environment into a room prior to operation. Notice if there is water condensation on cold surfaces.

Secure coolant hoses at the hose nozzles (e.g., with hose clamp) to prevent their accidental slipping.

Comply with all applicable and relevant safety requirements (regulations and guidelines). Implement the required actions and adopt suitable safety measures.

Ambient conditions



→ Do not reach for this product if it has fallen into liquid. There is a risk of deadly electrical shock. Unplug the system immediately.

AWARNING

□ Do not use this product in an area where it can fall or be pulled into water or other liquids.

ACAUTION

- Adopt suitable measures in case of differences from recommended conditions, e.g., using the equipment outdoors, installation in higher altitudes, conductive pollution or external condensation on the pump.
- Do not operate this product near flames.

NOTICE

To the best of our knowledge the equipment is in compliance with the requirements of the applicable EC-directives and harmonized standards (see "Declaration of Conformity") with regard to design, type and model. Directive EN 61010-1 gives in detail the conditions under which the equipment can be operated safely (see also IP degree of protection, "Technical data", pg. 27).

Operating conditions



- ➡ These pumps are not approved for operation in potentially explosive atmospheres. Do not operate the pumps in potentially explosive atmospheres.
- Pumps without the "⟨x⟩" mark on the rating plate are not approved for the pumping of potentially explosive atmospheres. Do not pump potentially explosive atmospheres with those pumps.
- Pumps bearing the "⟨x⟩" mark on their rating plates are approved for the pumping of potentially explosive atmospheres according to their classification II 3G IIC T3 X according to ATEX, but they are not approved for operation in potentially explosive at-

mospheres (see section (x) Important information: Equipment marking (ATEX)", pg. 25).

➡ The pumps are **not suitable** to pump any of the substances listed below.

Do not pump:

- unstable substances
- substances which react explosively under **impact** (mechanical stress) without air
- substances which react explosively when being exposed to **elevated temperatures** without air,
- substances subject to auto-ignition,
- substances which are inflammable without air
- explosive substances.
- → The pumps are not approved for operation below ground. Do not operate the pump below ground.



- Do not pump substances which may form deposits inside the pump. The pumps are not suitable for pumping substances which may form deposits inside the pump. Deposits and condensate in the pump may lead to increased temperatures even to the point of exceeding the maximum permitted temperatures.
- Check the inlet and outlet of the pump, if there is a danger of forming deposits inside the pump, e.g., in the pump chambers (the pump chamber is the part between diaphragm and head cover. See section "Replacing diaphragms and valves", pg. 99). Inspect the pump chambers regularly and clean if necessary.
- Consider interactions and chemical reactions of the pumped media. Ensure that the materials of the pump's wetted parts are compatible with the pumped substances, see section "Technical data", pg. 27.
 When changing the substances pumped, we recommend purging the pump with air or inert gas prior to changing the pumped media. Purging the pump will pump out residues and it will reduce the possibility of

reactions of the pumped substances with each other and with the pump's materials.

Safety during operation

A DANGER

- → Adopt suitable measures to prevent the release of dangerous, toxic, explosive, corrosive, noxious or polluting fluids, vapors and gases. To prevent any emission of such substances from the pump outlet, install an appropriate collecting and disposal system and take protective action for pump and environment.
- ➤ You must take suitable precautions to prevent any formation of explosive mixtures in the pump chamber or at the outlet of the pump. In case, e.g., of a diaphragm failure, mechanically generated sparks, hot surfaces or static electricity may ignite these mixtures. Use inert gas for gas ballast or venting, if necessary.
- → Drain appropriately or otherwise remove any potentially explosive mixtures at the outlet of the pump, or dilute them to non-explosive concentrations.
- Never operate this pump if it has a damaged cord or plug.

AWARNING

- If the pump is not working properly, has been dropped or has fallen into water, contact your pump service provider.
- Prevent any part of the human body from coming into contact with vacuum.
- Make sure that the exhaust pipeline cannot become blocked.
- Check the overpressure safety relief device at the exhaust waste vapor condenser at appropriate intervals.
- Avoid clogging of the exhaust vapor condenser caused by deposits or freezing solvents.

- Attention: At pressures above approximately 795 Torr (1060 mbar) the pressure reading becomes incorrect due to saturation of the pressure transducer. The display flashes. Release pressure immediately! Risk of bursting!
- Comply with applicable regulations when disposing of chemicals. Take into consideration that chemicals may be contaminated. Take adequate precautions to protect people from the effects of dangerous substances (chemicals, thermal decomposition products of fluoroelastomers). Use appropriate protective clothing and safety goggles.
- Interruption of the pump (e.g., due to power failure), failure of connected components or of parts of the supply, or change in parameters must not be allowed to lead to dangerous conditions. In case of a diaphragm failure or in case of a leak in the manifold, pumped substances might be released into the environment or into the pump housing or motor.

Comply with all notes regarding proper use of the pumps, as well as operation and maintenance guidance.

The residual **leak rate of the equipment** might render possible an exchange of gas, albeit extremely slight, between the environment and the vacuum system. Adopt suitable measures to prevent contamination of the pumped substances or the environment.

PC 3001 TE VARIOPro:

- Cold surfaces can absorb a great amount of gas, which may expand abruptly in case of warming. This may lead to unmanageable overpressure in the system, creating a risk of bursting!
- Check the coolant level of the condenser at appropriate intervals.
- Attention: Coolant may overflow unexpectedly, e.g., in case of large amounts of gas.

- Do not overfill the condenser. Lowest permissible coolant temperature: -112°F (-80°C).
- Maximum operating pressure: 16 psi (1.1 bar) absolute.



- Ensure that no parts of your clothing, hair or fingers can be caught or drawn in at the inlet of the pump. Never insert fingers or drop any other object into the inlet or outlet.
- Pumping at high inlet pressure may lead to overpressure at the gas ballast valve. Pumped gases or condensate might be expelled if the valve is open. If an inert gas supply is connected to the gas ballast, ensure that its inlet pipeline is not contaminated.
- You must take suitable precautions to prevent any dangerous situation from arising if the controller starts the pump, switches a coolant valve or opens a venting valve.
- Attention: If the controller is set to Autostart, the process will start immediately after a power failure without pressing any further key. It is your responsibility to ensure that automatic start-up of the system will not lead to any dangerous condition. Provide appropriate safety measures. Check prior to starting the process whether the option "Autostart" (menu: configuration) is enabled.



- Pay attention to the safety symbol "hot surfaces" on the equipment. Hot parts may cause burns if touched. Adopt suitable measures to prevent any danger arising from hot surfaces or electric sparks. Ensure that hot surfaces of the pump do not cause burns. Provide a suitable contact guard if necessary.
- Ensure that the coolant outlet pipe at the waste vapor condenser is always free and that it cannot get blocked.

PC 3001 TE VARIOPro:

Comply with all applicable safety measures and requirements when using cryogenic coolants (e.g., dry ice).

Attention: Coolant media may cause severe frostbite when coming in contact with skin!

- Prior to every use: Inspect the condenser for faults.
 There must be no damage on the glass surface. Do not use damaged components.
- Use only transport receptacles intended for coolants.
- Wear safety glasses and protective gloves.
- Do not clamp the covers of condensers or coolant receptacles. Allow pressure equalization between coolant and atmosphere.

NOTICE

Prevent the backpressure of gases and the backflow of condensates at the outlet.

Check the liquid level in the catchpots regularly and drain condensate in time to prevent overfilling. Install a level sensor (see "Accessories", pg. 94) for monitoring, if necessary.

Provide appropriate protective measures to allow for the possibility of failure and **malfunction**. The protective measures must also allow for the requirements of the respective application.

The CVC 3000 controller is powered by a short-circuitproof wide-range power supply with integrated overload protection.

A temperature sensor at the circuit board protects the motor: Current limitation in case the temperature at the circuit board raises above 158°F (70°C). At temperatures above 185°F (85°C) the pump is switched off. In case of a motor blockage (after 10 start-up attempts) the pump is switched off.

Note: Only manual reset is possible. Disconnect the pump from the power source. Identify and eliminate the cause of failure.

Maintenance and repair

NOTICE

In order to comply with laws (occupational, health and safety regulations, safety at work law and regulations for environmental protection) vacuum pumps, components and measuring instruments can only be returned when certain procedures (see section "Repair - Maintenance - Return - Calibration", pg. 113) are followed.

Take advantage of our service seminars, which put special focus on the maintenance and repair of vacuum pumps. For details and for the online "Instructions for repair" manual see www.vacuubrand.com.

In normal use, the lifetime of the diaphragms and valves is typically 15,000 operating hours. Bearings have a typical durability of 40000 h.

A DANGER

➡ Ensure that the pump cannot be operated accidentally. Never operate the pump if covers or other parts of the pump are disassembled.



- **⇒** Switch off the pump. Disconnect the electrical power cord and wait two minutes before starting maintenance to allow the capacitors to discharge.
- Note: The pump may be contaminated with process chemicals, which have been pumped during operation. Ensure that the pump is completely decontaminated before maintenance commences.

AWARNING

- Take adequate precautions to protect people from the effects of dangerous substances if contamination has occurred. Use appropriate protective clothing, safety goggles and protective gloves.
- **™** Wear parts have to be replaced regularly.
- Never operate a defective or damaged pump.
- Vent the pump before starting maintenance. Isolate

the pump and other components from the vacuum system. Allow sufficient cooling of the pump. Separate the pump from the coolant circuit and drain condensate, if applicable.

NOTICE

Ensure that **maintenance** is done only by suitably trained and supervised technicians. Ensure that the maintenance technician is familiar with the safety procedures which relate to the products processed by the pumping system. Only dismantle the pump as far as necessary.

(Important information: Equipment marking (ATEX)

VACUUBRAND equipment bearing mark (see rating plate)

II 3G IIC T3 X
 Internal Atm. only
 Tech. File Ref.: VAC-EX01

The classification II 3G IIC T3 X according to ATEX is only valid for the inner part (wetted part, pumped gas or vapor) of the equipment. The equipment is not suitable for use in external, potentially explosive atmospheres (environment).

The overall category of the equipment depends on the connected components. If the connected components do not comply with the classification of the VACUUBRAND equipment, the specified category of the VACUUBRAND equipment is no longer valid.

Vacuum pumps and vacuum gauges in category 3 are intended for connection to equipment in which during normal operation explosive atmospheres caused by gases, vapors or mists normally don't occur; or, if they do occur, are likely to do so only infrequently and for a short period only. Equipment in this category ensures the requisite level of protection during normal operation.

The use of gas ballast or the operation of venting valves is only permitted if thereby explosive atmospheres normally don't occur in the interior of the equipment or, if they do occur, are likely to do so only infrequently and for a short period.

The pumps are marked with "X" (according to EN 13463-1), i.e., restrictions of the operation conditions:

- The equipment is designated for a low degree of mechanical stress and has to be installed in a way so that it cannot be damaged from outside.
 - Pumping units have to be installed so that they are protected against shocks from the outside and against glass splinters in the event of breakage (implosion).

 The equipment is designated for an ambient and gas inlet temperature during operation of +10 to +40°C. Never exceed these ambient and gas inlet temperatures. If pumping / measuring gases which are not potentially explosive, extended gas inlet temperatures are permissible. See instructions for use, section "Gas inlet temperatures" or "Technical data".

After any intervention at the equipment (e.g., repair / maintenance) the ultimate vacuum of the pump has to be checked. Only if the pump achieves its specified ultimate vacuum is the pump's leak rate low enough to ensure that no explosive atmospheres will occur in the interior of the equipment.

After any intervention at the vacuum sensor, the leak rate of the equipment has to be checked.



Attention: This manual is not available in all languages of the EU. The user must not operate the device if he does not understand this manual. In this case a technically correct translation of the complete manual has to be available. The manual must be completely read and understood before operation of the device. All specified measures must be applied, or else must be replaced by equivalent measures at the user's own risk.

Technical data

General technical data valid for	r all p	umping units
Maximum pumping speed (ISO 21360)	cfm (m³/h)	1.2 (2.0)
Ultimate vacuum (absolute) without gas ballast*	Torr (mbar)	1.5 (2)
Ultimate vacuum (absolute) with gas ballast*	Torr (mbar)	3 (4)
Maximum permissible inlet and outlet pressure (absolute)	psi (bar)	16 (1.1)
Maximum permissible pressure difference between inlet and outlet	psi (bar)	16 (1.1)
Maximum permissible pressure (absolute) at gas ballast valve	psi (bar)	17.5 (1.2)
Permissible ambient temperature storage / operation	°F (°C)	14 to 140 / 50 to 104 (-10 to +60 / +10 to +40)
Permissible relative atmospheric moisture during operation (no condensation)	%	30 to 85
Maximum permissible installation altitude above mean sea level	ft (m)	6500 (2000)
Rated motor power	hp (kW)	0.21 (0.16)
No-load speed**	rpm	0 - 3000
Maximum permissible range of supply voltage (±10%) Attention: Observe specifications of rating plate!		100-120 V~ 50-60 Hz 200-230 V~ 50-60 Hz
Maximum rated current at: 100-120 V~ 50-60 Hz 200-230 V~ 50-60 Hz	A A	1.6 0.7
Device fuse Fuse of VACUU•BUS 24V DC supply		F7A fuse on the circuit board T0.5A slow blow fuse (with automatic reset) on the circuit board
Motor protection		current limitation (temperature sensor on the circuit board)
Degree of protection IEC 529		IP 20
Volume of catchpot	quarts (ml)	0.52 (500)
A-weighted emission sound pressure level*** (uncertainty K _{pA} : 3 dB(A))	dB(A)	42

Туре		PC 3001 VARIO ^{pro}	PC 3001 VARIO ^{pro} IK
Inlet		hose nozzle for tubing I.D. 1/4" / 3/8" (hose nozzle DN 6/10 mm)	hose nozzle for tubing I.D. 1/2" (hose nozzle DN 13 mm)
Outlet			tubing I.D. 3/8" DN 10 mm)****
Coolant connection (waste vapor condenser)		hose nozzle for tub (hose nozzle	oing I.D. 1/4" - 5/16" DN 6-8 mm)
Maximum permissible pressure of coolant at vapor condenser	psi (bar)	87 (ab (6 (abs	solute) solute))
Permissible range of coolant temperature (vapor condenser)	°F (°C)	.	
Dimensions L x W x H approx.	in (mm)	11.8 x 12.0 x 15.7 (300 x 306 x 400)	12.2 x 12.3 x 15.7 (309 x 312 x 400)
Weight approx.	lbs. (kg)	17.0 (7.7)****	18.3 (8.3)

- Ultimate vacuum at setting "Pump down" at speed "HI"
- Running smoothly only at motor speeds higher than 200 rpm Measurement according to EN ISO 2151:2004 and EN ISO 3744:1995 at 1500rpm and ultimate vacuum with exhaust tube at outlet.
- PC 3001 VARIOpro without condenser: Hose nozzle with silencer
- PC 3001 VARIOpro without condenser: 12.2 (6.9)

Туре		PC 3001 TE VARIOpro	PC 3001 VARIO ^{pro} emission condenser Peltronic
Inlet		hose nozzle for tul (hose nozzle	bing I.D. 1/4" / 3/8" DN 6/10 mm)
Outlet		hose nozzle for tubing I.D. 3/8" (hose nozzle DN 10 mm)	hose nozzle for tubing I.D. 5/16" (hose nozzle DN 8 mm)
Permissible range of coolant temperature	°F (°C)	-112 to 68 (-80 to +20)	-
Coolant capacity	quarts (ml)	0.3 (275)	-
Dimensions L x W x H approx.	in (mm)	13.2 x 10.2 x 18.9 (335 x 260 x 480)	11.8 x 14.6 x 15.7 (300 x 370 x 400)
Weight approx.	lbs. (kg)	18.1 (8.2)	24.9 (11.3)

Controller	CVC 3000
Pressure transducer	ceramic diaphragm (alumina), capacitive, absolute pressure, gas type independent
Display	LCD graphic display, illuminated
Pressure units / scale (selectable)	Torr, mbar or hPa
Measuring range (absolute)	810 - 0.1 Torr (1080 - 0.1 mbar)
Maximum control range with internal pressure transducer (absolute)*	795 - 0.1 Torr (1060 - 0.1 mbar)
Resolution	0.07 Torr (0.1 mbar)
Maximum permissible pressure at pressure transducer (absolute)	1125 Torr (1.5 bar)
Maximum permissible temperature of gaseous media**	continuous operation: 104°F (40°C), for short periods (less than 5 minutes) up to 176°F (80°C)
Measurement uncertainty (absolute) after careful adjustment and at constant temperature	<± 0.75 Torr (1 mbar)
Temperature coefficient	<± 0.05 Torr/K (0.07 mbar/K)
Ambient temperature range (operation)	50°F to 104°F (10°C to +40°C)
Ambient temperature range (storage)	14°F to 158°F (-10°C to +70°C)
Permissible relative atmospheric moisture during operation (no condensation)	30% to 85%
Maximum permitted current of connected valves (connected components)	4A
Degree of protection IEC 529 (front side)	IP 42
Venting connection	hose nozzle for hose I.D. 3/16" (4-5 mm)
Maximum admissible pressure at venting connection	17.4 psi (1.2 bar) absolute
Interface	RS-232 C

^{*} The actual vacuum control range in your application might be reduced due to ultimate vacuum of the pump, volume of gas present, etc.

^{**} if pumping potentially explosive atmospheres: 50 °F to 104 °F (+10°C to +40°C)



See manual of Peltronic emission condenser for technical data!

We reserve the right for technical modification without prior notice!

Gas inlet temperatures

Operating condition	Inlet pressure	Permitted range of gas temperatures at inlet
Continuous operation	> 75 Torr (100 mbar) (high gas load)	→ 50 °F to 104 °F (+10°C to +40°C)
Continuous operation	< 75 Torr (100 mbar) (low gas load)	⇒ 32 °F to 140 °F* (0°C to +60°C*)
Short-time (< 5 minutes)	< 75 Torr (100 mbar) (low gas load)	→ 14 °F to 176 °F* (-10°C to +80°C*)

^{*} if pumping potentially explosive atmospheres: 50 °F to 104 °F (+10°C to +40°C)

Wetted parts

Components	Wetted materials
Pump	
Housing cover	PTFE
Head cover	ETFE carbon fiber reinforced
Diaphragm clamping disc	ETFE carbon fiber reinforced
Diaphragm	PTFE
Valve	FFKM
Pumping unit	
Inlet pumping unit	PPS (PC 3001 VARIOpro IK: PP)
Outlet pumping unit	PET (PC 3001 without emission condenser: PTFE carbon reinforced)
Outlet pumping unit (PC 3001 VARIOpro emission condenser Peltronic)	ETFE / ECTFE
Tubing	PTFE
Screw-in fittings	ETFE / ECTFE
O-ring at the catchpot	Fluoroelastomer
Overpressure safety relief device at exhaust waste vapor condenser	Silicone rubber / PTFE film
Distribution head (inlet)	PPS glass fiber reinforced / PP (blind plug)
Waste vapor condenser IK / EK / TE, catchpot	Borosilicate glass
Emission condenser Peltronic	ETFE / ECTFE / PP / PA
Silencer	PBT / PVF / rubber
CVC 3000	
Sensor	Aluminum oxide ceramic
Sensor housing	PPS / glass fiber
Sensor seal	Chemically resistant fluoroelastomer
Venting valve seal	FFKM

We reserve the right for technical modification without prior notice!

Abbreviations

EK: Waste vapor condenser (emission condenser)

ETFE: Ethylene/Tetrafluoroethylene

ECTFE: Ethylene/Chlorotrifluoroethylene

FFKM: Perfluoro elastomer **FPM**: Fluoroelastomer

IK: Waste vapor condenser (inlet condenser)

PA: Polyamide

PBT: Polybutylene terephthalate **PET**: Polyethylene terephthalate

PP: Polypropylene

PPS: Polyphenylene sulfide PTFE: Polytetrafluoroethylene


PVF: Polyvinyl fluoride


TE: Dry ice waste vapor condenser


Pump parts


Position	Component
1	MD 1C VARIO chemistry
	diaphragm pump
2	CVC 3000 controller
3	Mains connection
4	ON/OFF switch
5	Inlet
6	Outlet
7	Gas ballast valve
8	Handle
9	Exhaust waste vapor con- denser


Position	Component
10	Catchpot
11	Coolant inlet
12	Coolant outlet
13	Dry ice vapor condenser
14	Distribution head
15	Inlet condenser
16	Peltronic emission condenser
17	Overpressure safety relief device

















Depending on technical version the connections of the VACUU•BUS cables are equipped with a nib.

When connecting the VACUU•BUS connections to the rear side of the controller position the nib (1) of the VACUU•BUS connection in the notch (2) of the controller connections.

Use and operation

When switching on the controller CVC 3000 for the very first time, a menu to select the language of the controller menu is displayed. Select the desired language (e.g., "English") by turning the selection knob and press to confirm. Then select the pressure unit ("mbar", "Torr" or "hPa") in the same way.

It is possible to access the language selection menu at any time by switching on the controller while keeping the selection knob pressed.

Installing a pump in a vacuum system



➡ If dangerous or polluting fluids could be released at the outlet, install an appropriate system to catch and dispose of those fluids.



- Connect a gas-tight exhaust line at the pump outlet if necessary. Always vent exhaust gases appropriately (e.g., into a fume hood).
- Never block the gas outlet. The exhaust line must always be free of obstructions (no back pressure) to ensure an unimpeded discharge of gas. The cross-section of the outlet tubing must be at least the size of the pump's exhaust connection.
- Maximum permissible pressure: 21.8 psi (1.5 bar) absolute.
- Attention: At pressures above approximately 795 Torr (1060 mbar) the pressure reading becomes incorrect due to saturation of the pressure transducer. The display will flash. Release pressure immediately! Risk of bursting!
- Particles and dust must not be aspirated. If necessary, you must install appropriate filters. You must ensure their suitability concerning gas flow, chemical resistance and resistance to clogging prior to use.

Make sure ventilation is adequate, especially if the pump is installed in an enclosure, or if the ambient temperature is elevated. Provide external ventilation, if necessary.

ACAUTION

Reduce the transmission of vibration. Prevent mechanical load due to rigid pipelines. Insert elastic hoses or flexible elements as couplings between the pump and rigid pipes.

Note: Flexible elements will compress or flatten when evacuated if not designed for use under vacuum.

- Hose connections at the pump inlet must always be gas tight.
- A power failure may cause accidental ventilation of the pump, especially if the gas ballast valve is open. If this constitutes a potential source of danger, take appropriate safety measures.
- Check the power source and the pump's rating plate to be sure that the power source and the equipment match in voltage, phase, and frequency.

NOTICE

The ON/OFF switch is at the left side of the pumping unit. After switching off the pump, wait minimum 60 sec. before switching on again.

Make sure ventilation is adequate to maintain recommended operating temperature. Keep a minimum distance of 2 in (5 cm) between the cooling fan and surrounding items (e.g., housing, walls, etc.), or else install an external automatic ventilation system.

Use connecting hoses with large diameter and keep them as short as possible to avoid flow losses. Locate the pump as closely as possible to the application.

Always install outlet tubing descending from the pump or provide other measures to avoid backflow of condensate towards the pump. Use a suitable valve to isolate the pump from the vacuum application. This is to allow the pump to warm up before pumping condensable vapors and to clean the pump after use before it is switched off.

When assembling, ensure **vacuum-tightness**. After assembly, check the whole system for leaks.

Secure hose connections at the pump appropriately, e.g., with hose clamps, to protect against accidental detachment.

To reduce pump noise emanating from the pump exhaust port, connect an exhaust hose or use a silencer (see "Accessories", pg. 94).

The VACUUBRAND controller CVC 3000 can only be operated with components compatible with the VACU-UBRAND VACUU•BUS system, (see "Accessories", pg. 94).


The vacuum controller CVC 3000 controls VACUUBRAND diaphragm pumps NT VARIO and VARIO-B, pumping units PC 30xx VARIO, and optional coolant and venting valves. Connected components (e.g., venting valve, level sensor, external pressure transducer 3000 series) are automatically identified and configurated. Identical components must be configurated beforehand; information upon request.

Do not use more than one controller within the same VACUU•BUS system.

Several controllers in the same VACUU•BUS system will interfere with each other and result in error messages of the connected components (pumps, valves).

CVC 3000

The CVC 3000 is equipped with an internal capacitive pressure transducer with ceramic diaphragm. It measures the actual pressure independently of the gas type, and with reference to the vacuum, i.e., absolute.



- Condensate and deposits will affect the measurement results. Clean the pressure transducer, if necessary. See section "Cleaning the pressure transducer", pg. 83.

Connecting components at the controller:




At the rear side of the controller are connections for e.g., an optional coolant valve and/or an external pressure transducer and/or an external venting valve, as well as a venting connection and the serial interface RS 232C.

- Pull the controller out of the housing. Be careful not to disconnect the measuring connection (PTFE tube)!
- Insert the cable of the component to be connected underneath the housing and plug into the controller. Do not apply off-axis forces when assembling or removing plug connections! Observe correct orientation of the plug.
- Insert controller into the housing.

Separator at inlet and exhaust waste vapor condenser:

Assembling the hose nozzle with union nut:

- Take the hose nozzle with attached compression ferrule and union nut out of the catchpot and put onto inlet connection.
- → Tighten the union nut by hand until you can feel the stop. Then tighten an additional 1/4 rotation with an open-ended wrench (size 17mm) for final installation.




Catchpots:

The catchpot at the inlet protects against droplets and particles from entering the pump.

- Enhances lifetimes of diaphragms and valves.
- Improves vacuum performance in applications with condensable vapors.

Both catchpots are coated with a protective layer to protect against shattering in case of breakage or implosion.

→ Assemble the catchpots at the inlet and at the outlet using joint clips.



Exhaust waste vapor condenser (PC3001 VARIO^{pro}):

→ Assemble the hose nozzles for coolant inlet (11) and coolant outlet (12) tubing and for the gas outlet (6) at the exhaust waste vapor condenser.

The **exhaust waste vapor condenser** enables an efficient condensation of the pumped vapors at the outlet.

- No backflow of condensates.
- Controlled recovery of condensates.
- Close to 100% solvent recovery.
- The isolation cover protects against glass splinters in case of breakage, acts as thermal insulation to avoid condensation of humidity and is intended to absorb shocks.
- → Attach the tubing of the coolant circuit to the respective hose nozzles (hose nozzles for tubing I.D. 1/4"-5/16" (6-8 mm), see image) at the waste vapor condenser.

NOTICE

Check all hose connections prior to starting operation of the cooling system.

Secure coolant hoses at the hose nozzles (e.g., with hose clamps) to prevent their accidentally slipping off.



▶ Prevent the discharge of dangerous gases and vapors to the surrounding atmosphere. If appropriate, connect the exhaust line to a suitable treatment system.

AWARNING

Never block the gas outlet ((8) hose nozzle for tubing I.D. 3/8" (10 mm)). The exhaust hose has always to be unobstructed and without back pressure to enable an unhindered discharge of gases and protect the pump valves from damage.

ACAUTION

- Note: Install the hoses of the cooling system in a way to avoid the flow / dripping of condensed water onto the pumping unit (especially cables and electronic parts, see also IP degree of protection, "Technical data", pg. 27.
- Ensure that the coolant outlet tubing is always unobstructed and that it cannot get blocked.
- Maximum permissible coolant pressure at the exhaust waste vapor condenser: 87 psi (6 bar) absolute. Outlet flow must always be unhindered.
- Comply with the maximum permissible coolant pressures of additional components in the coolant circuit (e.g., coolant valve).
- Avoid overpressure in the coolant circuit (e.g., caused by blocked or squeezed coolant hoses).
- Only install the optional coolant valve in the supply line of the exhaust waste vapor condenser.

Notes regarding the (dry) ice condenser (PC 3001 TE VARIO^{pro})



The **exhaust waste vapor condenser** enables an efficient condensation of the pumped vapors at the outlet.

- Close to 100% solvent recovery.
- The isolation cover protects against glass splinters in case of breaking, acts as thermal insulation to avoid the condensation of humidity and is intended to absorb shocks.

A DANGER

- → Adopt suitable measures to prevent the formation of explosive or flammable mixtures, use inert gas for venting if necessary.
- ▶ Prevent the discharge of dangerous gases and vapors to the surrounding atmosphere. If appropriate, connect the exhaust line to a suitable treatment system.
- → Adopt suitable measures to prevent the release of dangerous, toxic, explosive, corrosive, noxious or polluting fluids, vapors and gases when disposing of condensates.

AWARNING

- Cold surfaces can absorb a great amount of gas, which may expand abruptly in case of warming. This may lead to unmanageable overpressure in the system, creating a risk of bursting!
- Check the coolant level of the condenser at appropriate intervals.
- Attention: Coolant may overflow unexpectedly, e.g., in case of large amounts of gas.
- Do not overfill the condenser. Lowest permissible coolant temperature: -112°F (-80°C).
- Maximum operating pressure: 16 psi (1.1 bar) absolute.
- Never block the gas outlet ((6) hose nozzle for tubing I.D. 3/8" (10 mm)). The exhaust hose has always to be unobstructed and without back pressure to enable an unhindered discharge of gases and protect the pump valves from damage.

ACAUTION

- Prior to every use: Inspect the condenser for faults. There must be no damage on the glass surfaces. Do not use damaged components.
- Use only transport receptacles intended for coolants.
- Use safety glasses and protective gloves.
- Do not clamp the covers of condensers or coolant receptacles. Allow pressure equalization between coolant and atmosphere.
- Comply with all applicable safety measures and requirements when using cryogenic coolants.


NOTICE

Use the equipment **only as intended**, that is, for condensation of vapors at the pump outlet or inlet.

Suitable coolants: e.g., dry ice or ethanol-dry ice mixture or water-ice mixture.



- → Remove cap. Fill coolant into the coolant chamber. Put cap back in place. Do not clamp the cap.
- Check coolant level at appropriate intervals.
- → Check level of condensate at appropriate intervals and drain condensate if necessary.
- Wait until the condensate has liquefied, if necessary.



- Separate the inner part of the condenser from the vacuum installation to drain the coolant.
- → Remove the cap on top of the condenser. Turn the inner part of the condenser and lift to pull it out. Comply with regulations when disposing of chemicals.
- When reassembling check for the correct position of the seal between inner and outer parts of the condenser.

Notes concerning the operation of the inlet condenser IK



Attention: The inlet condenser has no overpressure safety relief device.

ACAUTION

 Note: Install the hoses of the cooling system in a way to avoid the flow / dripping of condensed water onto the pumping unit (especially cables and electronic parts), or use thermally insulated hoses to prevent condensation


- Ensure that the coolant outlet tubing at both condensers is always unobstructed and that it cannot get blocked.
- Water pressure shock at the condensers may cause breakage of the condenser coil!

Notes concerning the operation of the Peltronic emission condenser


NOTICE

Read the manual of the Peltronic emission condenser and observe the instructions contained in that manual!

Assembling the Peltronic emission condenser:



- → Assemble the Peltronic emission condenser with two attachment screws (Phillips screwdriver size 2) to the pumping unit (a).
- → Assemble the hose connection between pump outlet and condenser inlet (b).
- ➡ Slip connecting tube onto hose connection of the Peltronic emission condenser. Secure with hose clip.



→ Connect the VACUU•BUS cable from the CVC 3000 controller to the Peltronic emission condenser (c).

Notes concerning the operation of pumping units with silencer

NOTICE

Attention: Dust-laden gases, deposits and condensed solvent vapor can restrict air flow out the silencer. The resultant back pressure can lead to damage of pump bearings, diaphragms, and valves. Under those conditions, a silencer must not be used.

During operation



Vent and dispose of potentially dangerous gases or vapors at the outlet of the pump appropriately.

AWARNING

- Due to the high compression ratio, the pump might generate overpressure at the outlet. Check pressure compatibility with system components (e.g., exhaust tubing or exhaust valve) at the outlet. Ensure that the pump outlet is neither blocked nor restricted.
- Maximum ambient temperature: 104 °F (40 °C)
 Check the maximum temperatures, if installing the pump in a cabinet or a housing. Make sure ventilation is adequate, especially if the ambient temperature is elevated.

ACAUTION

- If the pump is installed at an altitude of more than 6500 ft (2000 m) above mean sea level, check compatibility with applicable safety requirements, and adopt suitable measures. There is a risk of the motor overheating due to insufficient cooling.
- Check compatibility with the maximally permitted pressure at outlet and the maximum pressure difference between inlet and outlet ports.

NOTICE

Do not start the pump if the **pressure difference between inlet and outlet ports exceeds max. 16.0 psi (1.1 bar)**. Attempts to start the pump at higher pressure difference may cause stalling and damage of the motor.

If pumping condensable vapors (water vapor, solvents, etc.), let the pump run with **gas ballast** to help purge any condensation in the pump.

Prevent internal condensation, transfer of liquids or dust. The diaphragms and valves will be damaged, if liquids are pumped in significant amounts.

Check the pump regularly for external soiling and deposits.

Clean the pump if necessary to avoid an increase of the pump's operating temperature.

Operation with silencer (optional) at the outlet: Operating the pump at a high inlet pressure or pumping dusty gases for a long time may cause clogging of the silencer. Check the silencer regularly and replace if necessary.

A temperature sensor at the circuit board protects the motor: Current limitation in the event the temperature at the circuit board raises above 158°F (70°C). At temperatures above 185°F (85°C) the pump is switched off. In the event of a motor blockage (after 10 start-up attempts) the pump is switched off.

Note: Only manual reset is possible. Disconnect the pump from the power source. Identify and eliminate the cause of failure.

Check ventilation slots regularly for dust/dirt. Clean if necessary. Avoid overheating (e.g., due to hot process gases).

A warm up period (approximately 15 min.) is required to ensure that the rated ultimate vacuum and pumping speed are attained.

Important notes regarding the use of gas ballast

Gas ballast is a continuous purge to keep the pump's interior as clean as possible and to reduce the possibility of condensation inside the pump.




→ Air and pumped media might react inside the pump or at the outlet of the pump and form hazardous or explosive mixtures, when you use air rather than inert gas for the gas ballast. This constitutes a risk of significant damage to equipment and/or facilities, a risk of personal injury or even loss of life.



Make sure that air/gas intake through the gas ballast valve can never lead to hazardous, explosive or otherwise dangerous mixtures. If in doubt, use inert gas.

NOTICE

To reduce condensation in the pump, do not pump vapor before the pump has reached its operating temperature. Open the gas ballast valve when pumping condensable vapors. Turn gas ballast cap to open valve.



For **condensable vapors** (water vapor, solvents, etc.):

- The gas ballast valve is open if the arrow on the gas ballast cap is pointing towards the pump.
- With gas ballast valve open, the ultimate vacuum will be reduced.
- Use inert gas for gas ballast to avoid the formation of explosive mixtures. **Attention**: maximum supply pressure of inert gas: 17.5 psi (1.2 bar) absolute.
- Close the gas ballast valve by turning the cap 180°.

In case of low boiling solvents (when the formation of condensate is unlikely), the use of gas ballast might be unnecessary. Operating the pump without gas ballast increases the solvent recovery rate at the exhaust waste vapor condenser.

Important notes concerning the operation of the exhaust waste vapor condenser



→ Connect the exhaust to a suitable treatment system to prevent the discharge of dangerous gases and vapors to the surrounding atmosphere.

AWARNING

- Never block the gas outlet ((6) hose nozzle for tubing I.D. 3/8" (10 mm)). The exhaust hose must always be unobstructed and without back-pressure to enable an unhindered discharge of gases.
- Check the overpressure safety relief device (17) at the

exhaust waste vapor condenser (9) regularly; replace if necessary. Check especially for deterioration, coalescence and cracks.

ACAUTION

- Ensure that the coolant outlet hose is always free and that it cannot get blocked.
- Maximum permissible coolant pressure at the exhaust waste vapor condenser: 87 psi (6 bar) absolute
- Comply with the maximum permissible coolant pressures of additional components in the coolant circuit (e.g., coolant valve).
- We strongly recommend installing an optional coolant valve (see "Accessories", pg. 94) in the supply line of the exhaust vapor condenser to save water and reduce the risk of water spill.
- Avoid overpressure in the coolant circuit (e.g., caused by blocked or kinked coolant hoses).
- Avoid any clogging of the exhaust vapor condenser caused by deposits or frozen solvents. Clean if necessary or use higher coolant temperatures.

NOTICE

In case of **condensation**: Check the liquid level in both catchpots (10) during operation. Check the liquid level regularly. Do not allow the catchpots to overfill. Drain catchpots in time to avoid overflow. Install a level sensor (see "Accessories", pg. 94) for monitoring, if necessary. The maximum liquid level is at approximately 80% of the total filling level to avoid problems when removing the catchpots.

Permissible range of coolant temperature at the exhaust waste vapor condenser:

5 °F to 68 °F (-15°C to +20°C)

Check hose connections prior to starting operation of the cooling system.

Check coolant hoses regularly during operation.

Removing the catchpots:

Stop process.

Catchpot at outlet:

Remove joint clip. Remove catchpot and drain condensate.

Catchpot at inlet:

Admit air or inert gas (via the pump inlet) to restore atmospheric pressure in the catchpot before attempting removal. Remove joint clip. Remove catchpot and drain condensate.

NOTICE

Reattach drained catchpots.



Important: Comply with regulations when disposing of solvents/condensates. Recycle if possible; purify if contaminated.

Shutdown & storage

The pump can be switched off under vacuum.

NOTICE

Short-term:

Has the pump been exposed to condensate?

- Allow the pump to continue to run at atmospheric pressure for a few minutes.

Has the pump been exposed to media which may damage the pump materials or form **deposits**?

- Check and clean pump heads if necessary.

Has the pressure transducer been exposed to media which may form deposits?

 Clean pressure transducer at the CVC 3000 controller if necessary.

Long-term:

- Take measures as described above regarding shortterm shutdown.
- Separate the pump from the application.
- Close inlet and outlet ports (e.g., with transport caps).
- Close the gas ballast valve.
- Drain catchpots.
- Store the pump under dry conditions.


CVC 3000 Vacuum controller

When switching on the CVC 3000 controller for the very first time, a menu to select the language of the controller menu is displayed. Select the desired language, e.g., "English" by turning the selection knob and pressing to confirm. Then select the pressure unit ("mbar", "Torr" or "hPa") in the same way.

It is possible to access the language selection menu at any time by switching on the controller while keeping the selection knob pressed.


After switching on the device, the **version number of the software** is displayed, followed by the preselected function and the pressure reading.

Attention: Do not assemble or remove plug connections off-axis! Orient the plug correctly before inserting. To connect additional components use VACUU•BUS Y-adapters and extension cables. If an external pressure transducer is connected, it is recognized automatically. Further information on how to use several sensors simultaneously is available upon request.




Selection knob

- Press to reach the set-up menu of the function
- Turn to choose the parameter you want to modify
- Press to select the parameter you want to modify
- Turn to change the set value of the parameter
- Press to confirm change of value and to reach further parameters, or to leave the set-up menu



Display and symbols




Selected function (displayed in the upper left corner):

A "function" is one of the following operation modes of the CVC 3000 controller:

Pump down / Vac control / Auto mode (only with VACUU•BUS-compatible VARIO pump) / Program / VACUULAN / Configuration

Other display symbols:

1013.2 Actual absolute pressure at the pressure transducermbar / Torr / hPa Preselected pressure unit



Vacuum control to a preset vacuum value (here: 100 mbar/Torr/hPa); (without / with VACUU•BUS-compatible VARIO pump)

Actual pressure is in the range "Set vacuum + hysteresis" (without VACUU•BUS-compatible VARIO pump) / Actual pressure = "Set vacuum" (with VACUU•BUS-compatible VARIO pump)



Flashing: The actual pressure is greater than the preset maximum value ("Maximum")



Minimum value ("Minimum") reached

00:00:00

Process runtime (only if process control is running)



Pump down (continuous pumping)



Pump symbol is displayed when pump is running. With a VACUU•BUS-compatible VARIO pump, the pump's motor speed is also displayed in % of full speed.



Time meter is running (in function "VACUULAN"); remaining time in minutes is displayed



In-line valve switched on



Venting valve switched on



Coolant valve switched on



PC symbol: controller is in remote operation



Control is running



Warning notice (if necessary in combination with other symbols), flashing



Level sensor activated; catchpots need to be emptied.



Peltronic emission condenser connected

Notes on selecting the function

The CVC 3000 controller can be adapted to the specific application by choosing the appropriate function depending on the connected components and the requirements of the application.

Automatic detection of the components

When switching on the controller, the configuration of the connected components is checked automatically.

Connected components (e.g., VACUU•BUS-compatible VARIO pumps, gauge heads 3000 series, valves, level sensors) are detected automatically and controlled by the CVC 3000 until the controller is switched off. Identical components must be configured beforehand; information upon request. Switch the controller off and on again to renew the configuration. The last mode of operation and the preselected values (e.g., for pressure, speed or time for automated switching off) are stored.

If the preselections are chosen appropriately, it is possible to start immediately if similar operating conditions are desired.

The controller features five functions and one configuration menu, see section "Menu guide". Each of these functions involves different menu options, which are presented automatically and reflect the connected components. The types of components connected (e.g., valves) determine the active menu items.

Changing the function:

- ⇒ Switch controller on.
- ▶ Press "START/STOP" key to terminate control in case control is running (e.g., if "Autostart" is activated).
- ➡ Press "MODE" key.
- ⇒ Select function with knob and press to confirm.
- Depending on the selected function and system components, the controller provides different operating control, as follows:

"Pump down"

- Manages the continuous speed control of the VACUU•BUS-compatible VARIO pump depending on preselected pressure and time settings.
- Coolant valve

"Vac control"

- With pressure preselection, controls a VACUU•BUS-compatible VARIO pump to maintain pinpoint control of that pressure.
- Coolant valve

"Auto mode"

- Provides fully automatic boiling point determination and adaptation with pinpoint precision, and optimization of pumping speed with VACUU•BUS-compatible VARIO pumps.
- · Coolant valve

"Program"

- Control pump based on time and pressure preselections, or "Auto mode".
- Coolant valve
- Venting valve

"VACUULAN"


- Use continuous speed control to manage VACUU•BUS-compatible VARIO pumps, based on pressure and time preselections.
- Coolant valve

"Configuration"

Preselections for

- Adjustment of the pressure transducer
- Interface RS-232
- Sensors (configuration and switching between several sensors)
- Display (brightness and contrast of the display, language, sound)
- Autostart (automatic restart after power failure)
- Defaults (reset the controller to factory set values)


Menu guide




Function


Pump down Vac control Auto mode Program VACUULAN Configuration


----- Back -----



Configuration	
Adjustment	760 Torr
RS-232	
Sensors	
Display	
Autostart	Off
Defaults	Cancel
Back	








/ACUULAN	1
	_

Set vacuum 19 Torr Switch on 150 Torr Delay 15 min ----- Graphic -----

*: or automatically after 20 seconds without action



Pump down function

Function definition:

- **➡** Continuous pumping with pressure and time settings
- Operation on demand of a speed controlled VACUU-BUScompatible VARIO pump


Preselections

- Use the selection knob to select the parameters. All parameters can be altered even while operation control is running.
- Speed: Preselection of the motor speed for pump down. The selection "HI" effects the maximum speed and best ultimate vacuum of the pump (with automatic speed reduction at ultimate vacuum). The "Speed" is adjustable in a range of 1-100% and to "HI".
- Minimum: The controller switches the pump off once the preset value for "Minimum" has been reached.
 - "Minimum" is adjustable in a range of 1-795 Torr (1-1060 mbar) or can be set to "Off".
 - A preset "Duration" (process time) has no effect if the process is stopped due to a preset "Minimum" before "Duration" is reached.
- Delay: "Delay" determines the time the coolant valve remains open after the process has been stopped.
 - The "Delay" is adjustable in a range of 1-300 minutes or can be set to "Off" ("Off" means that the coolant valve closes immediately when the process stops.).
- Duration: "Duration" determines the total process time since control start.
 - The process time is adjustable between 1-1440 minutes (24 h) or can be set to "Off". "Off" indicates that no endpoint for pump down is determined.
 - If a "Duration" is preset, the controller switches off the pump when the preset process time is reached, even if a preset "Minimum" is still not reached.

If neither "Minimum" nor "Duration" is preset, process control has to be stopped by pressing key "STOP".

The screen-shot shows the factory-set values.

Pump down	760 Torr	
Speed	HI	
Minimum	Off	
Delay	Off	
Duration	Off	
Graphic		
Back		



When selecting "Graphic" the display shows a pressure vs. time curve.

The timeline in the diagram adapts automatically to the process time.

Press the selection knob twice to return to the standard display.

Temporary switching from "Pump down" to "Vac control" or "Auto mode" (only if control is running):

- Press "MODE" key. The controller switches to "Vac control" function, the current vacuum is used as set value.
- Pressing "MODE" key again switches to "Auto mode" function. The controller adapts the boiling pressure starting from the current vacuum level.
- The preset function of the controller does not change due to this temporary switching. When pressing "STOP" key, the controller is set again to the "Pump down" function.

Adapting the pumping speed during pump down:

- Press the selection knob and turn.
- Turning the knob to the left reduces the speed.
- Turning the knob to the right increases the speed.

Vac Control function

Function definition:

- **▶** Vacuum control to a preset vacuum value
- Operation on demand of a speed controlled pump (VACUU•BUScompatible VARIO pump)


Preselections

- Use the selection knob to select the parameters. All parameters can be altered even while operation control is running.
- Set vacuum: The "Set vacuum" is the set point for vacuum control with pinpoint precision for VACUU•BUS-compatible VARIO pumps. The "Set vacuum" is adjustable in a range of 1-795 Torr (1-1060 mbar) or can be set to "Turbo". The selection "Turbo" leads to the optimum backing pressure for a turbomolecular pump.
- Speed: The maximum motor speed can be preselected (to control the pumping speed).
 - The "Speed" is adjustable in a range of 1-100% or can be set to "HI". The selection "HI" (recommended) provides the optimum pumping speed of the pump and therefore an optimum ultimate vacuum.
- Maximum: An upper pressure limit can be preselected. The pump switches off if the pressure limit is exceeded, e.g., at the end of suctions or filtrations. The pressure limit is only active once the pressure has gone below "Maximum".
 - The "Maximum" is adjustable in a range of 794-1Torr (1059 1 mbar) (at the least 1 Torr (mbar) higher than the "Set vacuum") and to "Off". "Off" means that no "Maximum" value is preset.
- Delay: "Delay" determines the time the coolant valve remains open after the process has been stopped.
 - The "Delay" is adjustable in a range of 1-300 minutes or can be set to "Off" ("Off" means that the coolant valve closes immediately when the process stops.).
- **Duration:** "Duration" determines the total process time since control start.

A preset "Duration" (process time) has no effect if the process is stopped due to a preset "Maximum" before "Duration" is reached. The "Duration" is adjustable between 1-1440 minutes (24 h) or can be set to "Off". "Off" means that no endpoint of the process is defined.

The screen-shots show the factory-set values.

Vac control	760 Torr	
Set vacuum	75 Torr	
Speed	HI	
Maximum	Off	
Delay	Off	
Duration	Off	
Graphic		
Back		



When selecting "Graphic" the display shows a pressure vs. time curve.

The timeline in the diagram adapts automatically to the process time. Press the selection knob twice to return to the standard display.

Temporarily switching from "Vac control" to "Auto mode" while process control is running:

Press "MODE" key. The controller switches to "Auto mode" and adapts the boiling pressure starting with the actual set value. The preset function of the controller does not change due to this switching. When pressing the "STOP" key, the controller is in "Vac control" function again.

Adjustment of the set vacuum during vacuum control:

Dynamic, interactive adaptation:

- Press the selection knob and keep pressed.
- Turning the knob for a 1/4 turn to the left causes pump down.
- Turning the knob for a 1/4 turn to the right causes venting.
- When the knob is released, the current pressure value is used as new set value.

Alternatively:

Fine tuning:

The set vacuum can be fine-adjusted by turning the selection knob while process is running.

- Turn the selection knob.
- A full turn causes a change of the set vacuum of 9 Torr (12 mbar).
- Turning the knob one detent causes a change of the set vacuum of 1 Torr (mbar).

Auto mode

Function definition:

➡ Control of a VACUU•BUS-compatible VARIO pump in "Auto mode":

Automatic detection of boiling points, and automatic adjustment of determined boiling points as process parameters change.

Preselections

- Use the selection knob to set the parameters.
- Sensitivity: The "Sensitivity" of the control determines the control speed. The "Sensitivity" is adjustable to "high", "normal" or "low". High sensitivity leads to a reduced pump-down speed, e.g., for small amounts of solvents or foaming processes. Use a low sensitivity for "non-critical" processes to reduce process time. Usually setting the "Sensitivity" to "normal" is appropriate.
- Speed: The maximum motor speed can be preselected (to limit the pumping speed).

The "Speed" is adjustable in a range of 1-100% or can be set to "HI". The selection "HI" (recommended) causes an automatic limitation of the adaptation depending on parameters determined during the process. Only in case of very sensitive processes is it advisable to reduce the maximum speed.


- Minimum: If the vacuum value reaches "Minimum" the process is stopped. Use "Minimum" for automatic process termination.
 - The "Minimum" is adjustable in a range of 2-795 Torr (2 1060 mbar), or can be set to "Auto" or to "Off".
 - When selecting "Auto" the controller switches off automatically at the end of the process (boiling plateau). This is recommended only for large amounts of solvents.
- Delay: "Delay" specifies the time the coolant valve remains open after process stop.
 - The "Delay" is adjustable in a range of 1-300 minutes or can be set to "Off" ("Off" means that the coolant valve closes immediately when the process stops.).

Duration: "Duration" determines the total process time since control start.

The "Duration" is adjustable between 1-1440 minutes (24 h) or can be set to "Off". A preset "Duration" (process time) has no effect, if the process is stopped earlier by reaching the preset "Minimum".

The screen-shot shows the factory-set values.

Auto mode	760 Torr	
Sensitivity	normal	
Speed	HI	
Minimum	Off	
Delay	Off	
Duration	Off	
Graphic		
Back		



When selecting "Graphic" the display shows a pressure vs. time curve.

The timeline in the diagram adapts automatically to the process time.

Press the selection knob twice to return to the standard display.

Temporary switching from "Auto mode" to "Vac control" function

- Press "MODE" key. The controller switches to "Vac control". The current pressure value is used and held as new set point.
- The preset function of the controller does not change due to this temporary switching. When pressing "STOP" key, the controller is set again to the "Auto mode".

Program function

Function definition:

▶ Permits ten programs to be defined and stored, each with up to ten program steps with preset values for vacuum and time.

☞ Edit:

Use to define the preset values for the process run:

Time: Defines either the process runtime for each program step to reach a preset vacuum level or, if programming a "Step", the runtime after having achieved the vacuum level. The total process runtime is shown in the base line. Attention: A preset runtime of 99:59:59 hours in the final program step will cause the process to run endlessly. Terminate the process by pressing the "STOP" key.

Vacuum: Vacuum level to be attained.

Venting valve: Operating a venting valve to reach a preset vacuum level.

"Step": "Step" causes pump down as fast as possible to the preset vacuum level. As soon as the vacuum level is reached the time meter starts running.

"Auto": Auto = \bot : indicates that the system will search for a boiling point automatically, and will automatically adapt to changes in the boiling point until a preselected time interval expires.

Auto = -: indicates that the system will automatically adapt to changes in the boiling point. The program step is finished when the selected time or pressure value has been reached.

Selecting "Auto" in combination with "Step" in one program step is not possible.

- **□ Open:** Choose program (Programs 0 9).
- Store: This command stores an edited program or the program of the last process to one of the storage spaces 0 9.
- **Delay:** "Delay" specifies the time the coolant valve remains open after process stop.


The "Delay" is adjustable in a range of 1-300 minutes or can be set to "Off" ("Off" means that the coolant valve closes immediately when the process stops.).

Editing:

- To select row: turn and press selection knob.
- To adjust parameter: turn the selection knob.
- To confirm parameter: Press selection knob. Controller will accept change and jump to the next parameter in the same row.
- After 5 seconds without a change, the parameter is assumed to be the current setting. Select the next row to edit or return to the Program menu.
- ➡ In case, store an edited program after having quit "Edit" by storing it to one of the storage spaces 0 - 9 (select "Store").

The screen-shot shows the factory-set values.

Program	760 Torr
Edit	
Open	0
Store	0
Delay	Off
Graphic	0
Back	



When selecting "Graphic", the display shows a pressure vs. time curve.

Program number, and the step number in that program, along with the vacuum setting, the actual current pressure and the actual runtime are displayed across the top.

The timeline in the diagram adapts automatically to the process time.

Press the selection knob twice to return to the standard display.

The most recent process (except in "VACUULAN" function) is stored in the temporary data memory as long as the controller stays switched on. This program can be transferred to a storage space and edited.

Once the program is finished, the clock symbol starts to flash. Confirm the end of the program by pressing START/STOP (clock symbol will disappear).

Attention: If "Autostart" is set to "On", the program will start again (time will be reset to 00:00:00) after a power failure or after switching the controller off/on. Only if the end of the program (clock symbol flashing) has been confirmed by pressing START/STOP, the program will not start again.

Attention: If the controller is set to "Defaults": "On", all stored programs will be deleted.

Application example

Example

VACUU•BUS-compatible VARIO vacuum pump with speed control (e.g., with a rotary evaporator): Degassing and automatic distillation with timing

Prog	gram				
No	hh:mm:ss	Vac	Vent.	Step	Auto
01 02 03 04 05 06 07 08	00:00:00 00:10:00 01:00:00 00:01:00 00:00:00 00:00:00 00:00:00	ATM 300 2 ATM 0 0 0 0 0	1	√ √	<u>↓</u> *
09 10	00:00:00	0			
	01:11:00	- Back	(

* If the pressure difference between the vacuum for degassing and the expected vacuum for distillation is very small (distillation vacuum >75% of the degassing vacuum), select the function "Auto •" (adapting the vacuum starting from the current pressure) instead of "Auto • " (at first searching the boiling point automatically, and then adapting the vacuum).

Program step 1 should be always a definite initial state, here atmospheric pressure (ATM). To reach this state definitely, set a tickmark at "Vent." and "Step" by pressing the selection knob.

In step 2, pumping begins, attempting to reach 300 Torr/mbar as quickly as possible ("Step"). Vacuum holds there for 10 minutes (degassing the solvent).

In step 3, "Auto

" causes an automatic search of a boiling point in the pressure interval between 300 Torr/mbar/hPa (depending on preset pressure unit) and 2 Torr/mbar/hPa, followed by automatic adaptation to changes in the boiling point. The following step starts either (1) once the cumulative process time reaches the set limit (1 hour/60 minutes), even if the preset pressure (2 Torr/mbar/hPa) has not been reached, or (2) if a vacuum of 2 Torr/mbar/hPa is reached, even if the preset time has not been completed.

Step 4 vents to atmospheric pressure as fast as possible and switches off the control after one minute.

VACUULAN function

Function definition:


- → Optimizes vacuum control for vacuum networks (e.g., VACUUBRAND VACUU•LAN)
- ➡ Permits on-demand operation of a speed-controlled pump (VACUU•BUS-compatible VARIO pump)

Preselections

- Use the selection knob to select the parameters.
- Set vacuum (the lower switch-off value): If the pressure drops below the "Set vacuum", a time-meter starts to run and the motor speed is reduced. When the pressure exceeds the "Set vacuum" pressure again, the time meter is reset. If the "Set vacuum" is not reached within 100 hours, the controller signals an error.
 - The "Set vacuum" is adjustable in the range of 1-795 Torr (1-1060 mbar).
- Switch on (the higher switching value): If the pressure exceeds this pressure, pumping down starts again.
 - The "Switch on" pressure is adjustable in the range of 2-795 Torr (2-1060 mbar).
 - In the event of a sudden high-pressure spike, pumping starts again even if the "Switch on" pressure has not been reached (pressure increase control).
- Delay: If the vacuum is below "Set vacuum" for longer than the "Delay" time, the pump is stopped. Pumping starts again in the event of a rapid pressure increase or if the "Switch on" level is exceeded.
 - The "Delay" is adjustable in a range of 1-300 minutes or can be set to "Off" ("Off" means that the pump stops immediately when the pressure drops below "Set vacuum".).

This screen-shot shows the factory-set values.

VACUULAN	760 Torr	
Set vacuum	19 Torr	
Switch on	150 Torr	
Delay	15 min	
Graphic		
Back		



When selecting "Graphic" the display shows a pressure vs. time curve.

The timeline in the diagram adapts automatically to the process time. Press the selection knob twice to return to the standard display.

Application examples

Assembly of a vacuum system

- Assemble the vacuum connection line between the vacuum pump and the vacuum application.
- Assemble the vacuum connection line between the controller and the vacuum application, if the controller is not part of a pumping unit.
- Assemble electrical connections.
- Connect coolant if necessary.

Vacuum for filtration and suction

- Select "Pump down" function.
- If necessary, set value for "Speed" (high or low pumping speed). Reduce the speed in case of fast sedimentation (formation of a filter cake).
- Set "Minimum" to a value which provides adequate suction but does not lead to evaporation of the solvent.
- Start process by pressing "START/STOP" key.

alternatively:

- Select "Vac control" function.
- Set "Set vacuum" to a value which does not lead to evaporation of the solvent.
- If necessary, set value for "Speed" (high or low pumping speed). Reduce the speed in case of fast sedimentation (formation of a filter cake).
- Set "Maximum" pressure setting so that pump will switch off at the end of the filtration process, or in the event that a filter cake cracks, leading to a sudden pressure increase.
- Start process by pressing "START/STOP" key.
- Tip for filtration: Adjust preset pressure to a value well above the boiling pressure of the solvent (e.g., for water >>15 Torr (20 mbar)). Set the maximum pressure to e.g., 375 Torr (500 mbar). Once the filtration has finished, the pressure increases and the pump is switched off automatically.

Vacuum for gel dryer, drying chambers and vacuum concentrators

- Select function "**Pump down**" function. "*Speed*" "HI" is recommended. For gel dryers set a lower speed if necessary (if the gels tend to crack).
- Set "Minimum" to prevent volatile components from evaporating. The process is stopped automatically as soon as "Minimum" is reached.
- Set a process time ("Duration") if necessary.
- Start process by pressing "START/STOP" key.

alternatively:

- Select "Vac control" function to dry at a predetermined vacuum level.
- Set "Set vacuum" to the preferred evaporation vacuum of the solvent.
- Set a process time ("Duration") if necessary.
- Start process by pressing "START/STOP" key.

Vacuum for distillation and evaporation (e.g., rotary evaporator)

Fully automatic determination and adaptation of the boiling point with a VACUU•BUS-compatible VARIO pump (recommended)

- Select "Auto mode".
- Start process by pressing "START/STOP" key.
- The "Auto mode" allows a fully automatic distillation even if the boiling vacuum is unknown. With solvent mixtures, the vacuum is reduced until all solvents or volatile components are evaporated (with respect to the ultimate vacuum of the pump and the bath temperature).
- If "Minimum" is set, the controller switches off the pump when the preset vacuum value is reached. The "Minimum" should be well below the boiling vacuum of the solvent to be evaporated and above the ultimate vacuum attainable in the apparatus. If the "Minimum" is set to "Auto", the controller automatically switches off the pump at the end of the evaporation (recommended for large solvent quantities only). The setting of "Duration" (process runtime) has no effect if the pump is switched off due to "Minimum" before "Duration" is over.

- When setting a value for "Duration" the controller switches off the pump when "Duration" has passed even if a preset "Minimum" is still not reached.
- If neither "Minimum" nor "Duration" is preset, pumping down has to be finished by pressing the "START/STOP" key.

alternatively:

Semi-automatic distillation and evaporation

- Select function "Pump down".
- Start process by pressing "START/STOP" key.
- Observe process. As soon as evaporation starts, press "MODE" key (switching to "Vac control"). The vacuum level is kept constant (at the boiling pressure). Fine tuning of the vacuum value is possible by turning the selection knob.

Pressing "MODE" key a second time switches to "Auto mode" causing the vacuum level to be automatically adapted to changes of the boiling pressure.

alternatively:

- Select "Vac control" function.
- Set a maximum "Speed", to select a faster or slower process.
- To set "Maximum" is usually not necessary, unlike filtrations, because the pressure does not increase at the end of the evaporation.
- Set a value for "Duration" if the process should be terminated automatically after a definite time.
- Set "Set vacuum" depending on the solvent and the temperature.
- Start process by pressing "START" key.
- To temporarily switch to "Auto mode": Press "MODE" key. The controller switches to "Auto mode". The setting of the controller does not change due to this switching. After pressing "START/STOP" key the controller is in "Vac control" again.

Vacuum for VACUU•LAN networks

- Select function "VACUULAN".
- Set "Set vacuum" to a pressure which can be reached reliably in the vacuum network. Take account of the ultimate vacuum of the pump and of the system's leak rate in case of no vacuum demand.
- Set "Switch on" pressure appropriately to ensure sufficient vacuum for all connected applications.
- Set "Delay" if necessary.
- Start process by pressing "START/STOP" key.

Configuration

In the "Configuration" menu the device parameters are preselected. After 20 seconds without action the function "Configuration" and its submenus (except submenu "Sensors") are quit automatically without storing any possibly changed parameter.

Preselections

- Use the selection knob to select the parameters.
- Adjustment: Adjustment of the pressure transducer under vacuum and/or at atmospheric pressure, see also section "Readjustment of CVC 3000", pg. 80.
 - Adjustment to atmospheric pressure is carried out at an absolute pressure value between 795 525 Torr (1060 700 mbar). This is especially helpful in high elevation laboratories. Adjustment under vacuum may be done at an absolute vacuum value between 0 15 Torr (0 20 mbar). In the range between 15 to 525 Torr (20 to 700 mbar) no adjustment is possible; ---- Torr is displayed.
- RS-232: Configuration of the interface, setting of parameters and commands, see section "Interface".
 - Baud rate can be set to 19200, 9600, 4800 or 2400, parity on "8-N-1", "7-O-1" or "7-E-1", Handshake on "no", "Xon-Xoff" or "RTS-CTS" and remote on "On" or "Off".
- Sensors: Selection of the pressure transducer to be controlled (maximum 4 external sensors).
- Display: Selection of the device parameters "Brightness" between 0 100%, "Contrast" between 0 100%, "Sound" "On" or "Off", "Units" "mbar", "hPa" or "Torr", "Language" "German", "English", "French", "Italian", "Spanish", "Turkish", "Korean", "Chinese", "Portuguese", "Russian", "Polish", "Dutch", "Japanese", "Finnish".
- Autostart: If "Autostart" is set to "On" the controller restarts a running process automatically after a power failure. If this is unwanted, set "Autostart" to "Off".



Attention: If "Autostart" is preselected, the process starts immediately after power failure without pressing any further key. It is the user's responsibility to ensure that no dangerous status of the system due to the automatic start-up can occur and to provide appropriate safety measures. If necessary, the user has to check **prior to starting the process** if the option "Autostart" is enabled.

Defaults: If "Defaults" is set to "Load", the controller is reset to factory set values. All stored programs and parameters are deleted.

This screen-shot shows the factory-set values.

Configuration	
Adjustment	760 Torr
RS-232	
Sensors	
Display	
Autostart	Off
Defaults	Cancel
Back	

Please continue with part 2 of this manual.



Technology for Vacuum Systems

Instructions for use

Part II of II



Part II:

Readjustment -

Interface parameters -

PC 3001 VARIOpro PC 3001 TE VARIOPro PC 3001 VARIOPTO IK

Accessories - Maintenance PC 3001 VARIOpro EK Peltronic

Chemistry pumping unit with speed control

Contents

Part I	1
Reset / Language selection	8
Safety information!	
Important information!	
General information	
Intended use	13
Setting up and installing the equipment	14
Ambient conditions	17
Operating conditions	17
Safety during operation	19
Maintenance and repair	
(Ex) Important information: Equipment marking (ATEX)	
Technical data	
General technical data valid for all pumping units	
Gas inlet temperatures	
Wetted parts	
Abbreviations	
Pump parts	
Use and operation	
Installing a pump in a vacuum system	
Notes regarding the (dry) ice condenser	
Notes concerning the operation of the inlet condenser IK	40
Peltronic emission condenser	46
Notes concerning the operation of pumping units with silencer	
During operation	
Important notes regarding the use of gas ballast	
Important notes concerning the operation of the	
exhaust waste vapor condenser	49
Shutdown & storage	51
CVC 3000 Vacuum controller	
Menu guide	57
Pump down function	59
Vac Control function	
Auto mode	
Program function	
Application example	

VACUULAN function	69
Application examples	71
Vacuum for filtration and suction	
Vacuum for gel dryer,	
drying chambers and vacuum concentrators	72
Vacuum for distillation and evaporation (e.g., rotary evaporator)	
Vacuum for VACUU•LAN networks	
Configuration	75
Part II	.77
Readjustment of CVC 3000	
Calibration in the factory	
Cleaning the pressure transducer	
Interface parameters	
Setting of the interface	
Read commands "CVC 2000"	
Write commands "CVC 2000"	
Read commands "CVC 3000"	
Write commands "CVC 3000"	
Accessories	94
Troubleshooting	
Replacing diaphragms and valves	
Cleaning and inspecting the pump heads	
Disassembling the housing cover	
at the side of the emission condenser	. 103
Replacing the diaphragm	. 105
Assembling the housing cover at	
the side of the emission condenser	. 108
Disassembling the housing cover	
at the side of the ON/OFF switch	
Assembling the housing cover at the side of the ON/OFF switch	
Assembling the fittings	
Cleaning and replacing components	
Repair - Maintenance - Return - Calibration	
Warranty	
EC Declaration of Conformity of the Machinery	117
China PoHS	110


Readjustment of CVC 3000

NOTICE

The vacuum gauge was adjusted using factory standards, which are traceable through regular calibration in an accredited laboratory (DAkkS calibration laboratory) to the German national pressure standard. Depending on the process and/or accuracy requirements, check the adjustment and readjust if necessary. For readjustment, the device has to be adjusted both at atmospheric pressure as well as under vacuum but only if the reference pressures are known with certainty. The adjustment mode can be activated only if the process control is inactive. Press "START/STOP" key, if necessary. In the range between 15 to 525 Torr (20 to 700 mbar) no adjustment is possible;

---- Torr is displayed.

Adjustment at atmospheric pressure



An adjustment at atmospheric pressure is only possible if the pressure is higher than 525 Torr (700 mbar).

Vent the measurement connection of the CVC 3000 and/or the vacuum system. Make sure that the pressure transducer is at atmospheric pressure.

- → In "Configuration" menu, select program "Adjustment" at the controller.
- ➡ Use the selection knob to adjust the reading to the current atmospheric pressure.
- → Press the selection knob to confirm.

Note: To determine the actual atmospheric pressure, use an accurate barometer or get accurate reading from the weather service, or a nearby airport or other reliable source (taking into account the difference in altitude between the source and the laboratory).

Adjustment under vacuum

0 mbar


An adjustment under vacuum is only possible if the pressure is lower than 15 Torr (20 mbar) absolute.

Evacuate the measurement connection of the CVC 3000 to a pressure < 0.1 Torr (mbar) (e.g. by applying a good two-stage rotary vane pump).

- → In "Configuration" menu, select program "Adjustment" at the controller.
- The reading is automatically adjusted to "zero".
- ➡ Press the selection knob to confirm.

Note: Adjustment under vacuum with an actual pressure higher than 0.1 Torr (mbar) reduces the accuracy of the measurement. If the pressure is significantly higher than 0.1 Torr (mbar), adjustment to a reference pressure is recommended.

Adjustment at a reference pressure



Instead of adjustment under vacuum to a pressure < 0.1 Torr (mbar), adjustment to a precisely known reference pressure within the range of 0..... 15 Torr (20 mbar) is possible. Evacuate the measurement connection of the CVC 3000 to a pressure within 0 15 Torr (0.....20 mbar).

- → In "Configuration" menu, select program "Adjustment" at the controller.
- The reading is automatically adjusted to "zero".
- → Use the selection knob to adjust the display to the reference pressure at the vacuum line within the range of 0 15 Torr (0.....20 mbar).
- ➡ Press the selection knob to confirm.

Note: The accuracy of the value of the reference pressure will directly affect the accuracy of the adjustment. If the nominal ultimate vacuum of a diaphragm pump is used as reference vacuum, the accuracy of the controller might be doubtful. The diaphragm pump may not achieve the specified value (due to condensate, poor condition, failure of valves or diaphragm, leaks).

Calibration in the factory

Control of measuring equipment

The VACUUBRAND DAkkS calibration laboratory is accredited by the Deutsche Akkreditierungsstelle GmbH (national accreditation body of the Federal Republic of Germany) for the measurable variable pressure in the pressure range from 7.5*10⁻⁴ Torr to 975 Torr (10⁻³ mbar to 1300 mbar) in accordance with the general criteria for the operation of testing laboratories defined in the DIN EN ISO/IEC 17025:2000 series of standards (accreditation number D-K-15154-01).

The DAkkS is signatory to the multilateral agreements of the European cooperation for Accreditation (EA) and of the International Laboratory Accreditation Cooperation (ILAC) for the mutual recognition of calibration certificates.

Rely on calibration in the VACUUBRAND calibration laboratory:

- To meet the requirements of the DIN ISO 9000ff and 10012 series of standards regarding the calibration of inspection, measuring and test equipment at specified intervals.
- To document that the vacuum gauges calibrated are traceable to national standards of the PTB (Physikalisch-Technische Bundesanstalt; German national institute for science and technology and the highest technical authority of the Federal Republic of Germany for the field of metrology and certain sectors of safety engineering).

To order DAkk	κS calibration	of the CVC	3000 pressure	transducer,
order number:				900215

Cleaning the pressure transducer

- → Attention: Never use a pointed or sharp-edged tool to clean the pressure transducer.
- Never touch the ceramic diaphragm of the pressure transducer with hard objects.
- ➡ Fill the measurement chamber with a solvent (e.g., benzene) and allow sufficient cleaning time. Observe all regulations concerning usage and disposal of solvents!
- → Drain the solvent and dispose of in accordance with regulations. Repeat cleaning if necessary.
- ➡ Rinse the measurement chamber several times with alcohol in order to remove all solvent residues.
- → Allow the pressure transducer to dry.
- ➡ Readjust the pressure transducer if necessary.

Readjustment of the controller CVC 3000

See section "Readjustment of CVC 3000", pg. 80.

Interface parameters

The CVC 3000 controller is equipped with a serial interface (RS 232C, nine-pin Sub-D-plug).

- Plug-in or remove the cable (cable RS 232C) from the interface only if the equipment is switched off.
- The interface is **not** electrically isolated from the measuring circuit.

The controller is fully operable via the serial interface. Measuring results, preselections and the status of the controller can be read at any time.

The factory-set read and write commands are completely compatible with the VACUUBRAND CVC 2000 controller (see sections "Read / Write commands CVC 2000"). An extended instruction set is available using the command "CVC 3" (see sections "Read / Write commands CVC 3000").

Setting of the interface

Set the interface parameters directly at the controller CVC 3000. <u>The factory set values are underlined.</u>

Edit and confirm the interface parameters in the "Configuration" menu in "RS-232" submenu using the selection knob.

⇒ Baud: 2400, 4800, 9600 or 19200

⇒ Parity: 8-N-1, 7-O-1 or 7-E-1

➡ Handshake: Off, Xon-Xoff or <u>RTS-CTS</u>

Remote: On or Off


→ Timeout: Sending 1s, receiving 10s.

In remote mode (Remote On, with the "PC symbol" in the display) all keys at the controller are inoperable.

To return to the manual operation of the controller, set the controller to "Remote off" in menu configuration: Switch off the controller. Then switch the controller back on, and press the selection knob within 2s.

- → A maximum of ten commands per second is possible.
- ⇒ Read commands and commands "REMOTE", "CVC", and "STORE" can always be sent. The sending of other write commands is only possible, if "Remote on" is selected.
- → The commands have to be written in capital letters.
- → Command and parameter have to be separated by a blank.
- → The string is terminated with <CR> or <LF> or <CR><LF>.
- ➡ The response of the controller is always terminated with <CR><LF>.
- Numerical values and parameters can be written without leading zeros.
- ➡ The response of the controller always includes leading zeros.

Pin assignment RS-232 C



2: RxD

3: TxD

4: DTR

5: Mass

7: RTS

8: CTS

9: +5V (Bluetooth)

Read commands "CVC 2000"

Command	Operation	Response	Description
IN_PV_1	current pressure	XXXX mbar/ Torr/hPa	unit according to preselections
IN_PV_2	current frequency	XX.X Hz	pump speed
IN_CFG	device set preselections	0XXXX 1XXXX 2XXXX 3XXXX X0XXX X1XXX XX0XX XX1XX XXX0X XXX1X XXXX0 XXXX1	VACUU•LAN continuous pumping vacuum control without automatic vacuum control with automatic no coolant valve coolant valve no venting valve venting valve no automatic switch off automatic switch off remote operation on
IN_ERR	error code	1XXX X1XX XX1X XXX1	fault at pump electronics overpressure maloperation mode pressure transducer last command to interface incorrect
IN_STAT	status of process control	0XXX 1XXX X0XX X1XX XX00 XX01 XX02 XX03 XX10 XX11 XX20 XX21 XX22 XX23 XX30 XX31 XX32 XX32 XX33	coolant valve closed coolant valve open venting valve closed venting valve open VACUU•LAN: inactive VACUU•LAN: pumping down, current pressure > selected pressure VACUU•LAN: pumping down, time for automatic switching off is running VACUU•LAN: system is switched off continuous pumping: not active continuous pumping; active vacuum control: not active vacuum control: current pressure equals set vacuum (±1 Torr/mbar) vacuum control: current pressure below set vacuum automatic: not active automatic: determining boiling point automatic: adjusting boiling point automatic: system is switched off

Write commands "CVC 2000"

Command	Operation	Parameter	Description
OUT_MODE	function	1 2 3 30 31 32	continuous pumping vacuum control without automatic vacuum control with automatic optional: sensitivity: low optional: sensitivity: normal optional: sensitivity: high
OUT_SP_1	set vacuum	XXXX	unit (mbar/Torr/hPa) according to pre- selection; see respective function for parameter range
OUT_SP_V	set vacuum with venting*	XXXX	unit (mbar/Torr/hPa) according to pre- selection; see respective function for parameter range
OUT_SP_2	set frequency	XX.X	motor speed in Hz (99.9 for "HI"; 99.8 for 3000 rpm)
OUT_SP_3	vacuum for switch on (VACUU•LAN)	XXXX	unit (mbar/Torr/hPa) according to pre- selection; see respective function for parameter range
OUT_SP_4	delay	XX:XX	hh:mm (hours:minutes)
OUT_SP_5	vacuum for auto- matic switching off	XXXX	unit (mbar/Torr/hPa) according to pre- selection; see respective function for parameter range
OUT_SP_6	time for automatic switching off (VACUU•LAN)	XX:XX	hh:mm (hours:minutes)
START	starting process control		
STOP	stopping process control	1 2	termination of process control termination of process control and storage of the current pressure as new set point
REMOTE	remote operation**	0 1	set controller to local operation set controller to remote operation
OUT_VENT	driving venting valve	0 1	close venting valve (not automatically) open venting valve (process control stopped)

^{*} Pressure setting with venting is only possible in "Vac control" function if a venting valve is connected and configured, and vacuum control is started. The venting valve opens automatically if the actual pressure is at least 7.5 Torr (10 mbar) below the preset pressure. Automatic venting becomes inactive if vacuum control is stopped (by pressing "START/STOP" or "VENT"), a pressure value is set using the command OUT_SP_1, or if the function is changed. Activate the command OUT_SP_V again if necessary.

** If remote operation is selected or deselected, the user has to ensure that no dangerous status of the system can occur due to the change of the mode of operation, and must take appropriate safety precautions, especially if selecting remote operation interferes with a locally operated active process.

Read commands "CVC 3000"

Command	Operation	Response	Description
IN_PV_1 c	current pressure	XXXX.X mbar/Torr/hPa	unit according to preselections
IN_PV_2	current speed	XXX%	1-100% or "HI"
IN_PV_3	time	XX:XX h:m	process runtime (hours:minutes)
IN_PV_X	pressure	XXXX.X XXXX.X	pressure of all connected sensors, unit (mbar/Torr/hPa) according to preselections
IN_PV_T	operation time of the controller	XXXXdXXh	operation time in days and hours
1 2 3 4 5 6 7 8 9	device set preselections Language: D: German 1: English 2: French 3: Italian 4: Spanish 5: Turkish 6: Korean 7: Chinese 8: Portuguese 9: Russian A: Polish B: Dutch C: Japanese D: Finnish	0XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX	VACUU*LAN Pump down Vac control Auto mode Program measuring device y: 0D: language* (hexadecimal) pressure unit mbar pressure unit hPa autostart off autostart on acoustic signal off acoustic signal on VARIO pump not connected VARIO pump connected VMS not connected VMS connected in-line valve not connected in-line valve not connected coolant valve not connected venting valve not connected venting valve connected tenting valve connected remote module not connected level sensor connected remote module connected remote module connected y: 19: sensor quantity remote operation on

Command	Operation	Response	Description
		0XXXXX	pump off
		1XXXXX	pump on
		X0XXXX	in-line valve closed
		X1XXXX	in-line valve open
		XX0XXX	coolant valve closed
		XX1XXX	coolant valve open
		XXX0XX	venting valve closed
		XXX1XX	venting valve open
		XXXX0X	VACUU•LAN
	status process	XXXX1X	Pump down
IN_STAT	control	XXXX2X	Vac control
		XXXX3X	Auto mode
		XXXX4X	Program
		XXXX5X	measuring device
		XXXXX0	control off
		XXXXX1	pump down -
			determining boiling point
		XXXXX2	set vacuum reached -
			boiling pressure found
		XXXXX3	current pressure below set vacuum
			- automatic switch-off
		0XXXXXXX	no fault at pump
		1XXXXXXXX	fault at pump
		X0XXXXXX	no fault at in-line valve
		X1XXXXXXX	fault at in-line valve
		XX0XXXXXX	no fault at coolant valve
		XX1XXXXXX	fault at coolant valve
		XXX0XXXXX	no fault at venting valve
		XXX1XXXXX	fault at venting valve
IN ERR	fault status	XXXX0XXXX	no overpressure
_		XXXX1XXXX	overpressure
		XXXXX0XXX	no fault at pressure transducer
		XXXXX1XXX	fault at pressure transducer
		XXXXXXX0XX	catchpot not full
		XXXXXX1XX	catchpot full
		XXXXXXXXXXXX	no external fault
		XXXXXXXX1X	external fault
		XXXXXXXXX0	last interface command correct
INL CD 4	201	XXXXXXXXX1	last interface command incorrect
IN_SP_1	set vacuum	XXXX mbar/Torr/hPa	unit according to preselections
IN_SP_2	maximum speed	XXX%	speed in % (1-100% or "HI")
IN_SP_3	switching pressure	XXXX mbar/Torr/hPa	switching pressure for VACUU•LAN or two point control; unit according to preselections

Command	Operation	Response	Description
IN_SP_4	delay	XX:XX h:m	hours:minutes (00:00 = Off)
IN_SP_5	switch off pressure	XXXX mbar/Torr/hPa	"Maximum" for "Vac control", "Minimum" for "Pump down") unit according to preselections
IN_SP_6	runtime	XX:XX h:m	process runtime (hours:minutes)
IN_SP_P1y	time	XX:XX:XX h:m:s	time in program step y (09) (hours:minutes:seconds)
IN_SP_P2y	pressure	XXXX mbar/Torr/hPa	pressure in program step y (09) unit according to preselections
		0	no venting valve in program step y
IN_SP_P3y	venting valve	1	(09) venting valve in program step y (09)
IN_SP_P4y	Step	0 1	no "Step" in program step y (09) "Step" in program step y (09)
IN_SP_P5y	Auto	0 1	no "Auto" in program step y (09) "Auto" in program step y (09)
IN_PV_Sx	current pressure of pressure trans- ducer x	XXXX mbar/hPa/Torr	pressure of pressure transducer x (order of numbering according to display in "Sensors" menu)
IN_VER	version	CVC 3000 VX.XX	software version

Write commands "CVC 3000"

Command	Operation	Parameter	Description
		0	VACUU•LAN
		1	Pump down
		2	Vac control
OUT MODE	function	3	Auto mode
OO1_WODE	Turicuon	30	optional: sensitivity: low
		31	optional: sensitivity: normal
		32	optional: sensitivity: high
		4	Program
		yXXX	y: 0D: language+ (hexadecimal), see
OUT_CFG configur (bus mon	configuration		"Read commands CVC 3000"
		X0XX	pressure unit mbar
		X1XX	pressure unit Torr
	_	X2XX	pressure unit hPa
	(bus monitoring)	XX0X	Autostart off
		XX1X	Autostart on
		XXX0	acoustic signal off
		XXX1	acoustic signal on

Attention (OUT_MODE): If control is running, it is only possible to switch either from 1 to 2, or from 2 to 3, or from 3 to 2. The set vacuum is adopted in each case.

Command	Operation	Parameter	Description
OUT-SP_1	set vacuum	XXXX	unit according to preselection; see respective function for parameter range
OUT_SP_V	set vacuum with venting	XXXX	unit according to preselection; see respective function for parameter range
OUT_SP_2	speed	XXX	speed in % or "HI"
OUT_SP_3	start-up pressure	XXXX	unit according to preselection; see respective function for parameter range
OUT_SP_4	delay	XX:XX	hh:mm (hours:minutes)
OUT_SP_5	switch-off pressure	xxxx	unit according to preselection; see respective function for parameter range
OUT_SP_6	switch-off time	XX:XX	hh:mm (hours:minutes)
OUT_SP_PL	open program	Х	program 09
OUT_SP_PS	store program	Х	program 09
OUT_SP_P1y	time	XX:XX:XX +XX:XX:XX	total runtime until program step y (09) or time for program step y (09) (additive)
OUT_SP_P2y	pressure	XXXX	pressure at program step y (09) unit according to preselection
OUT_SP_P3y	venting valve	0 1	no venting valve in program step y (09) venting valve in program step y (09)
OUT_SP_P4y	Step	0 1	no "Step" in program step y (09) "Step" in program step y (09)
OUT_SP_P5y	Auto	0 1 2	no "Auto" in program step y (09) "Auto " in program step y (09) "Auto " in program step y (09)
START			started
STOP		0 1 2	Stop and delete fault Stop Stop and adopt the set vacuum
REMOTE*		0 1	Remote off Remote on
ECHO**		0 1	Echo off Echo on, write command with return value
CVC		2 3	CVC 2000 commands CVC 3000 commands***
OUT_VENT		0 1 2	venting valve closed venting valve open venting until atmospheric pressure (788 Torr (1050 mbar) at maximum)
STORE			store settings permanently, if "ECHO = 1" after realization

Command	Operation	Parameter	Description
OUT_SENSOR		1 29	internal sensor external sensors (if connected)

- * If remote operation is selected or deselected, the user has to ensure that no dangerous status of the system can occur due to the change of the mode of operation, and must also take appropriate safety precautions, especially if selecting remote operation interferes with a locally operated active process.
- ** With command "ECHO 1" a return value can be activated at write commands. A return value is only given if the command is performed correctly.
- *** After being switched on, the controller is in "CVC 2" mode by default. Send "CVC 3" and "STORE" to permanently set the controller RS 232C commands to the extended set "CVC 3000".

Accessories

External pressure transducer VSK 3000,	. 636657
Small flange connection KF DN 16	. 699939
Coolant valve VKW-B, 24 V=	. 674220
Venting valve VBM-B / KF 16, 24 V=	674217
Level sensor	699908
VACUU•BUS Y-type adapter	. 636656
VACUU•BUS extension cable, 6.6ft (2m)	. 612552
VACUU•BUS wall jack	. 636153
Serial cable RS 232C, 9-pin, Sub-D	. 637837
Upgrade kit emission condenser	. 699922
(for PC 3001 VARIOpro without emission condenser)	
Silencer (with connection hose)	. 636588

Attention: Dust-laden gases, deposits and condensed solvent vapor can restrict air flow out the silencer. The resultant back pressure can lead to damage of pump bearings, diaphragms, and valves. Under those conditions, a silencer must not be used.

Spare parts:

Troubleshooting

Fault	Possible cause	Remedy
☐ No display.	Electrical power cord not plugged in, electri- cal supply failure?	✓ Plug in power cord. Check fuse.
	Controller CVC 3000 or pumping unit switched off?	✓ Switch on controller and/ or pumping unit.
	→ VACUU • BUS cable between pump and controller not plugged in at controller?	✓ Plug in VACUU • BUS cable at CVC 3000 controller.
	Other than above mentioned causes?	✓ Contact local distributor.
☐ Display disappears.	→ Too much load (e.g., valves) connected?	✓ Check current draw of the connected devices.
	Short circuit at connected valves?	✓ Replace valves.
	◆ Short circuit at the RS 232 plug?	✓ Check plug and cable.
	Other than above mentioned causes?	✓ Contact local distributor.
Pressure reading incorrect.	Pressure transducer decalibrated?	✓ Readjust CVC 3000.
	Humidity in the measurement chamber?	✓ Let the pressure trans- ducer dry, e.g., by pump- ing. Readjust if neces- sary. Determine and eliminate the cause for humidity.
	Pressure transducer contaminated?	✓ See "Cleaning the pres- sure transducer".
	Other than above mentioned causes?	✓ Contact local distributor.
☐ Digital pressure reading is flashing, display shows "0.0".	Pressure transducer not correctly adjusted under vacuum?	✓ Adjust CVC 3000 cor- rectly.
No digital pressure reading.	Pressure transducer defective?	✓ Contact local distributor.

Fa	nult	Po	ssible cause	Re	emedy
	Digital pressure reading is flashing, one blip*.	→	Overpressure at the pressure transducer, pressure > 795 Torr (1060 mbar)?	\ \	Release pressure immediately (risk of bursting).
	Warning triangle and black valve symbol are flash- ing, two blips*.	→	External venting valve removed or defective?	✓	Connect valve or replace with a new one or reconfigure without valve.
	Warning triangle and valve symbol are flashing, three blips*.	→	Pump and in-line valve connected?	1	Disconnect in-line valve; switch controller off/on to reconfigure.
	Warning triangle and coolant valve symbol are flashing, four blips*.	→	Coolant valve removed or defective?	1	Check connection cable of the valve; or use new valve or reconfigure without valve.
	No digital pressure reading. Warning triangle is flashing, five or seven blips*.	→	Five blips: External pressure transducer defective or removed?	✓	Connect pressure trans- ducer or replace with a new one or reconfigure without pressure trans- ducer.
		→	Seven blips: Internal pressure transducer defective?	1	Contact local distributor.
	Warning triangle and pump symbol are flashing, six blips*.	→	Pump and VMS** (Vacuum Management System) connected?	✓	Remove VMS. Restart controller.
		→	Fault at the VARIO pump or at the VMS?	✓	Check pump and/or VMS, restart controller.
		→	Connecting cable from pump or VMS removed?	✓	Check cable connections.
	Clock symbol is flashing.	•	Preselected process time is over?	√	Confirm by pressing START/STOP key.
	Internal venting valve does not respond, valve symbol is not displayed.	→	External pressure transducer connected and active?	✓	Select internal pressure transducer or connect external venting valve.
	Venting valve does not respond, valve symbol is displayed.	→	Venting valve contami- nated?	1	Clean valve.

Fa	nult	Po	ssible cause	R	emedy
	"Vac control" function: Control stops, "arrow up" is flashing.	→	Preset maximum pressure exceeded?	✓	Confirm by pressing START/STOP key. Change maximum pressure value if necessary.
	"Pump down" function: Control stops, "arrow down" is flashing.	→	Pressure below preset minimum pressure?	1	Confirm by pressing START/STOP key. Change minimum pressure value if necessary.
	No function is displayed. No menu.	→	No controllable device (valve, VARIO pump, VMS) connected?	√	Connect devices or use controller as measuring device.
	Controller does not respond when pressing keys (ex- cept ON/OFF). PC symbol is dis- played.	→	Controller in remote mode?	1	Control CVC 3000 via interface or switch off remote mode.
	Controller does not respond when operating any keys. No change after switching off/on.			1	Contact local distributor.
	Pump does not start or stops im- mediately. Warning triangle and pump symbol are flash- ing.	•	Pump has been exposed to condensate?	1	Allow pump to run for some minutes at maximum speed with atmospheric pressure at the inlet.
		•	Overpressure in outlet line?	✓	Remove blockage in line, open valve.
	Pump does not achieve its ultimate vacuum or usual pumping speed.	→	Centring ring at small flange connection not correctly positioned, or leak in the pipeline or vacuum system?	1	Check pump directly, then check connection, pipeline and vacuum system if necessary.
		•	Wrong setting at controller?	√	Select function "Pump down" with speed set to "HI" and check again.
		→	Long, narrow vacuum line?	✓	Use lines with larger diameter, length as short as possible.
		→	Pump has been exposed to condensate?	√	Allow pump to run for some minutes with atmospheric pressure at the inlet to purge.

Fault	Possible cause	Remedy
☐ Pump does not achieve its ultimate vacuum or usual pumping speed.	Deposits have been formed inside the pump?	✓ Clean and inspect the pump heads.
	Diaphragms or valves damaged?	✓ Replace diaphragms and/ or valves.
	Outgassing substances or vapor generated in the process?	✓ Check process parameters.
	→ Pressure below "Mini- mum" in Auto mode?	✓ Change switch off pres- sure ("Minimum") if neces- sary.
	→ Pump too hot?	Allow pump to cool down. Determine and eliminate the cause of overheating.
☐ Pump too noisy.	→ Atmospheric or high pressure at the pump inlet?	✓ Connect hose or silencer to pump outlet. Be careful not to cause outlet over- pressure, especially with condensable vapors.
	Diaphragm crack or diaphragm clamping disc loose?	✓ Perform maintenance.
	Other than above mentioned causes?	✓ Contact local distributor.
☐ Pump seized.		✓ Contact local distributor.

^{*} only if "Sound" "On" is selected

Note: All error messages comprising a flashing warning triangle have to be confirmed (deleted) by pressing the START/STOP key. Solve the problem (see "Remedy"), then press the START/STOP key to delete the error message.

- → A service manual with exploded view drawings, spare parts list and directions for repair is available on request.
- The service manual is intended for trained service people only.

^{**} VMS: Vacuum management system to switch non-VARIO pumps

Replacing diaphragms and valves

Please read section "Replacing diaphragms and valves" completely before starting maintenance.

The pictures may show other versions of pumps. This does not change the method of replacing diaphragms and valves.

A DANGER

Never operate the pump if covers or other parts of the pump are disassembled.



- ➡ Before starting maintenance, disconnect the electrical power cord. Wait two minutes after isolating the equipment from AC power to allow the capacitors to discharge.
- ➡ Ensure that the pump cannot be operated accidentally.
- Note: The pump might be contaminated with the process chemicals that have been pumped during operation. Ensure that the pump is decontaminated before maintenance.
- ➡ Avoid the release of pollutants.

and protective gloves.

AWARNING

- Never operate a defective or damaged pump.
- Take adequate precautions to protect people from the effects of dangerous substances that may have contaminated the pump and may be released upon disassembly. Ensure that the maintenance technician is familiar with the safety procedures which relate to the products processed by the pumping system. Use appropriate protective clothing, safety goggles
- Allow sufficient cooling of the pump before starting maintenance.
- Vent the pump and isolate it from the vacuum system before you start maintenance.

NOTICE

Ensure that maintenance is done only by suitably trained and supervised technicians.


The valves and diaphragms are wear parts. If the rated ultimate vacuum is no longer achieved or in case of increased noise level, the pump interior, the diaphragms and the valves must be cleaned and the diaphragms and valves must be checked for cracks or other damage.

All bearings are encapsulated and are filled with long-life lubricant. Under normal operating conditions, the drive system is maintenance free.

In demanding circumstances, it may be efficient to check and clean the pump heads on a regular basis. In normal use, the lifetime of the diaphragms and valves is typically 15,000 operating hours.

- Prevent internal condensation, transfer of liquids or dust. The diaphragms and valves will be damaged if liquid is pumped in significant amount.
- Carry out maintenance frequently if the pump is exposed to corrosive media or in case of deposits.
- Regular maintenance will improve the lifetime of the pump and also protect both users and the environment.


Service kit MD 1C (diaphragms, valves, diaphragm key)696828




Tools required (metric):

- Diaphragm key width 46 mm
- Open end wrench width 14 / 17 mm
- 4 / 5 mm wide Allen key
- 2.5 mm wide slotted screwdriver
- Phillips screwdriver size 2
- Torx driver T10
- Flat pliers

Cleaning and inspecting the pump heads




Remove catchpots (10) at inlet and outlet (see "Use and operation", pg. 38).




Detach the coupling of the hose connection (M) below the housing cover (A).

- Open the hose clip (N) with a slotted screwdriver.
- → Pull the tubing off the hose connector.



Opening the hose clip:


→ Apply slotted screwdriver as shown and turn.



PC 3001 VARIOPTO / PC 3001 VARIOPTO IK

Disassemble the exhaust vapor condenser.

- ➤ Loosen the union nut at the inlet of the exhaust vapor condenser.
- Remove the 4 screws affixing the counter holder (O) of the exhaust vapor condenser with a Torx driver T10.
- ➡ Remove the exhaust vapor condenser. In doing so pull the PTFE hose out of the inlet of the exhaust vapor condenser.



PC 3001 VARIOPTO IK

Disassemble the inlet condenser.


- ► Loosen the union nut at the inlet of the pump.
- → Remove the 4 screws affixing the counter holder of the exhaust vapor condenser with a Torx driver T10.
- → Remove the inlet condenser. In doing so pull the PTFE hose out of the inlet of the inlet condenser.



PC 3001 VARIOPro TE

Disassemble the emission condenser TE.

- ➤ Loosen the union nut at the inlet of the emission condenser TE.
- Remove the 2 screws affixing the mounting plate of the emission condenser TE with a Phillips screw driver size 2.
- → Remove the emission condenser TE. In doing so pull the PTFE hose out of the inlet of the emission condenser TE.



PC 3001 VARIOPTO EK Peltronic

Disassemble the Peltronic emission condenser. Detach the coupling of the hose connection at the Peltronic emission condenser.


- Open the hose clip with a slotted screwdriver.
- → Pull the tubing off the hose connector.
- → Remove the 2 screws affixing the mounting plate of the Peltronic emission condenser with a Phillips screw driver size 2.
- → Remove the Peltronic emission condenser. In doing so pull the PTFE hose out of the inlet of the Peltronic emission condenser.
- Service only one side of the pump at a time to avoid the mixing of parts.



➤ Loosen the union nut (K) of the hose connection next to the gas ballast valve with an open-ended wrench (w/f 17).



- → Turn the fitting (L) with an open-ended wrench (w/f 14) to detach the hose from the pump head (1/4 of a turn at maximum).
- Do not remove the elbow fitting from the pump head; during reassembly a leak may result.




► Loosen the screw affixing the handle (use 5 mm wide Allen key) at one housing cover.

Disassembling the housing cover at the side of the emission condenser



- ► Lay the pumping unit on its side with the pump heads to be maintained at the top. Support the pumping unit appropriately.
- → Disassemble the housing cover (A) to check the valves (B).
- ➡ Unscrew six Allen screws with a 4mm wide Allen key. Remove the housing cover with housing cover insert (A) together with head covers (C) and valves (B).
- Never use a pointed or sharp-edged tool to remove parts (e.g., screwdriver). We recommend using a rubber mallet or compressed air (to be blown carefully into port).

View of the disassembled pump head parts



Pump head parts:

A: Housing cover with insert

B: Valves

C: Head cover

D: Diaphragm clamping disc with square head screw

E: Diaphragm

F: Diaphragm support disc

G: Washer(s)

H: Connecting rod

I: Housing

J: Housing bearing flange

K: Union nut

L: Fitting

M: Hose connection



- → Remove the head cover (C) carefully from the housing cover (A). Note position and alignment of valves (B). Remove the valves.
- Replace valves if necessary.
- Use petroleum ether or other industrial solvent to remove deposits. Do not inhale vapors.

Replacing the diaphragm




Check diaphragms (E) for damage and replace if necessary.




- ➡ Lift diaphragm carefully sidewise.
- Never use a pointed or sharp-edged tool to lift the diaphragm. If necessary, press down the diaphragm clamping disc of the adjacent pump head to raise the diaphragm into its uppermost turning point position.
- ⇒ Use the diaphragm key to grip the diaphragm support disc (F) below the diaphragm.
- → Press down the diaphragm clamping disc to bring the diaphragm into its lower turning point position. Unscrew diaphragm support disc (F) with diaphragm (E) and diaphragm clamping disc (D).
- ➡ Check for washers (G) between the diaphragm support disc (F) and the connecting rod (H). Do not mix the washers from the different pump heads, since these are set at the factory to ensure proper pump performance. Make sure that the original number is reassembled at the individual pump head.
- Too few washers: The pump will not attain vacuum specification. Too many washers: Diaphragm clamping disc will hit head cover, causing noisy operation and possibly causing the pump to seize up.

If the old diaphragm is difficult to separate from the diaphragm support disc, immerse assembly in naphtha or petroleum ether. Do not inhale vapors!



- → Position new diaphragm (E) between diaphragm clamping disc with square head screw (D) and diaphragm support disc (F).
- Note: Position diaphragm with pale side towards diaphragm clamping disc (facing pump chamber).




- Make sure that the square head screw of the diaphragm clamping disc is correctly seated in the guide hole of the diaphragm support disc.
- ► Lift the diaphragm at the side. Place the diaphragm carefully together with diaphragm clamping disc and diaphragm support disc in the diaphragm key.
- Avoid damage of the diaphragm: Do not excessively bend or crease the diaphragm.



- Assemble the original number of washers (G) between diaphragm support disc (F) and connecting rod (H).
- Screw diaphragm clamping disc (D), diaphragm (E), diaphragm support disc (F), and washers (G) to connecting rod (H).
- → Optimum torque for the diaphragm support disc: 3 ft·lb_f (4 Nm).
- If necessary, put the pumping unit in its upright position to screw the diaphragm clamping disc to the connecting rod. Subsequently lay the pumping unit again on its side.




 Bring the diaphragms (E) into a position, in which they are in contact with the housing (I) and centered with respect to the bore.



- → Put on head covers (C).
- Pay attention to the correct orientation of the head covers (see figure below).
- Make sure that the diaphragms stay centered with respect to the bores so that they will become clamped uniformly between housing (I) and head covers (C).
- ▶ Put the valves (B) in place. See figure below for the correct position of the valves:

Inlet side of pump head: The valve tongue points at the kidney-shaped orifice in the valve seat (1).

Outlet side of pump head: The valve is oriented the opposite direction as the valve at the inlet side. Round orifice under the valve tongue (2).



Assembling the housing cover at the side of the emission condenser

- → Put on housing cover (A).
- Move housing cover slightly to ensure that the head covers are correctly positioned.



- → Screw in the Allen head screws at the head cover in a diagonal pattern with a 4 mm wide Allen key, loosely at first, to align, then tighten.
- Maximum torque: 4.4 ft·lb, (6 Nm).

Disassembling the housing cover at the side of the ON/ OFF switch



- ► Lay the pumping unit on its side with the pump heads to be maintained at the top. Support the pumping unit appropriately.
- → Disassemble the housing cover (A) to check the valves (B).
- → Unscrew six Allen screws with a 4mm wide Allen key. Remove the housing cover with housing cover insert (A) together with head covers (C) and valves (B).
- Never use a pointed or sharp-edged tool to remove parts (e.g., screw-driver). We recommend using a rubber mallet or compressed air (to be blown carefully into port).



- Remove the head cover (C) carefully from the housing cover (A). Note position and alignment of valves (B). Remove the valves.
- Replace valves if necessary.
- Use petroleum ether or other industrial solvent to remove deposits. Do not inhale vapors.

For replacing the diaphragm refer to the section "Replacing the diaphragm" above.


Assembling the housing cover at the side of the ON/OFF switch

- → Put on housing cover (A).
 Pay attention to a correct guidance of the connection hose towards the inlet.
- Move housing cover slightly to ensure that the head covers are correctly positioned.



- Screw in the Allen head screws at the head cover in a diagonal pattern with a 4 mm wide Allen key, loosely at first, to align, then tighten.
- Maximum torque: 4.4 ft·lb, (6 Nm).

Assembling the fittings



Attach the handle at the housing cover (use 5 mm wide Allen key)



Slip the hose onto the hose connector by turning the fitting (L) with an open-ended wrench w/f 14



- → Tighten the union nut (K) of the hose connection with an open-ended wrench w/f 17.
- Tighten the union nut first by hand and then tighten one full turn using the open ended wrench.



PC 3001 VARIOPTO / PC 3001 VARIOPTO IK

Assemble the exhaust vapor condenser.

- → Feed the PTFE hose from the pump outlet into the inlet of the exhaust vapor condenser.
- → Mount the condenser with the counter holder (Torx screws T10) to the pump.
- ➡ Fasten union nut.



PC 3001 VARIOPTO IK

Assemble the inlet condenser.

- Slip the hose from the inlet of the pump onto the hose connector of the inlet condenser.
- → Mount the condenser with the counter holder (Torx screws T10) to the pump.
- ➡ Tighten the union nut first by hand and then tighten one full turn using the open ended wrench.



PC 3001 VARIOPTO TE

Assemble the emission condenser TE.

- ➤ Feed the PTFE hose from the pump outlet into the inlet of the emission condenser TE.
- → Attach the mounting plate of the emission condenser TE with 2 screws at the housing cover of the pumping unit; use a Phillips screw driver size 2. Pay attention to the cage nuts in the groove of the housing cover.
- → Fasten union nut.



PC 3001 VARIOPTO EK Peltronic

Assemble the emission condenser Peltronic.

- Slip the hose from the outlet of the pump onto the hose connector of the emission condenser Peltronic.
- → Attach the hose connection with hose clip. Close hose clip with flat pliers.
- → Attach the mounting plate of the emission condenser Peltronic with 2 screws at the housing cover of the pumping unit; use a Phillips screw driver size 2. Pay attention to the cage nuts in the groove of the housing cover.



- Slip connecting hose onto hose connection of fitting below the housing cover.
- ➡ Close hose clip with flat pliers.



→ Assemble catchpots (10) with joint clips.

Checking the ultimate vacuum

→ After any intervention at the equipment (e.g., repair / maintenance) the ultimate vacuum of the pump has to be checked. Only if the pump achieves its specified ultimate vacuum, the pump's leak rate is low enough to ensure that no explosive atmospheres will occur in the interior of the equipment.

After any intervention at the vacuum sensor the leak rate of the equipment has to be checked.

If the pump does not achieve the ultimate vacuum:

- Whenever the diaphragms and valves have been replaced, a break-in period of several hours is required before the pump achieves its ultimate vacuum.
- In case of an unusual noise, switch off pump immediately and check clamping disc positions.

If the specified ultimate vacuum is not achieved, and if this does not change after the break-in period:

Check hose connectors at pump heads for leaks. If necessary recheck valve seats and pump chambers.

Cleaning and replacing components



Replacing the overpressure safety relief device:

- → Loosen the union nut at the inlet of the exhaust vapor condenser.
- ⇒ Pull the PTFE hose out of the inlet of the exhaust vapor condenser.
- ➡ If necessary, pull off the old pressure relief valve and install the new one. Check for correct position of the PTFE-film under the pressure relief valve.
- Feed the PTFE hose into the inlet of the exhaust vapor condenser. Fasten union nut.

Catchpot

at the spherical ground joint of the catchpot at the inlet

Repair - Maintenance - Return - Calibration

IMPORTANT

Every employer (user) is held responsible for the health and safety of his employees. This also applies to service personnel performing repair, maintenance, return or calibration.

The **health and safety clearance form** informs the contractor about any possible contamination of the device and forms the basis for the risk assessment.

In case of devices which have been in contact with biological substances of risk level 2 contact the VAC-UUBRAND service absolutely before dispatching the device. These devices have to be completely disassembled and decontaminated by the user prior to shipment. Do not return devices which have been in contact biological substances of risk level 3 or 4. These devices cannot be checked, maintained or repaired. Also decontaminated devices must not returned to VACUUBRAND due to a residual risk.

The same conditions apply to on-site work.

No repair, maintenance, return or calibration is possible unless the correctly completed health and safety clearance form is returned. Devices sent are rejected if applicable. Send a completed copy of the health and safety clearance form to us in advance. The declaration must arrive before the equipment. Enclose a second completed copy with the product.

Remove all components from the device that are no original VACUUBRAND components. VACUUBRAND will not be responsible for lost or damaged components that are no original components.

Drain the device completely of fluids and residues. Decontaminate the device. Close all openings airtight especially if using substances hazardous to health.

To expedite repair and to reduce costs, please enclose a detailed description of the problem and the product's operating conditions with every product returned.

If you do not wish a repair on the basis of our **quotation**, the device may be returned to you disassembled and at your expense.

In many cases, the components must be cleaned in the factory prior to repair.

For cleaning we use an environmentally friendly water based process. Unfortunately the combined attack of elevated temperature, cleaning agent, ultrasonic treatment and mechanical stress (from pressurised water) may result in damage to the paint. Please mark in the health and safety clearance form if you wish a repaint at your expense just in case such a damage should occur. We will also replace parts for cosmetic reasons at your request and at your expense.

Before returning the device

Pack the device properly, if necessary, please order original packaging materials at your costs.

Mark the package completely

Enclose the completed health and safety clearance form.

Notify the carrier of any possible contamination if required.

Scrapping and waste disposal

Dispose of the equipment and any components removed from it safely in accordance with all local and national safety and environmental requirements. Particular care must be taken with components and waste oil which have been contaminated with dangerous substances from your processes. Do not incinerate fluoroelastomer seals and O-rings. You may authorize us to dispose of the equipment at your expense. Otherwise we return the device at your expense.

Warranty

VACUUBRAND shall be liable for insuring that this product, including any agreed installation, has been free of defects at the time of the transfer of risk.

VACUUBRAND shall not be liable for the consequences of improper handling, use, servicing or operation of this product or the consequences of normal wear and tear of wearing parts such as diaphragms, seals, valves, vanes, condensers, oil and the breakage of glass or ceramic parts, for the consequences of chemical, electrochemical or electrical influences or the failure to follow the instructions in this manual.

Claims for defects against VACUUBRAND shall be limited to one year from delivery. The same shall apply to claims for damages irrespective of legal grounds.

For further information on general terms and conditions refer to www.vacuubrand.com.

Health and safety clearance form								
1.	Device (Model):							
2.	Serial no.:							
3.	Reason for return / malfunction:							
4.	Has the device been used in a copper process step (e.g., semiconductor production): □ yes	□ no					
5.	Substances (gases, liquids, solids, biological material, e. g. bacteria, viruses) in contact with the device / which have been pumped:							
6.	Risk level of the used biological material: none 1 2* * Contact the VACUUBRAND service absolutely before dispatching the device. ** Devices which have been in contact with biological substances of risk level 3 or 4 tained or repaired. Also decontaminated devices must not returned to VACUUBR	cannot be	checked, main-					
7.	Radioactive contamination:	\square yes	□ no					
8.	Prior to return to the factory the device has been decontaminated: Description of the decontamination method and the test / verification procedure:	□ yes	□ no					
	All parts of the device are free of hazardous, harmful substances: O.Protective measures required for service staff:	□ yes	□ no					
11	I. If the paint is damaged, we wish a repaint or a replacement of parts for reason of ap (repaint and replacement at customer's expense):	pearance □ yes	□ no					
12	2. Legally binding declaration We assure for the returned device that all substances, which have been in contact w section 5 and that the information is complete and that we have not withheld any informations - where applicable - have been taken listed in section "Repair - Maintenan By our signature below, we acknowledge that we accept liability for any damage cau plete or incorrect information and that we shall indemnify VACUUBRAND from any c from third parties. We are aware that as expressed in § 823 BGB (Public Law Code liable for injuries or damages suffered by third parties, particularly VACUUBRAND er handling/repairing the product. Shipping of the device must take place according to responsible.	ormation. Voce - Returnsed by properties as recording to the contract of German or the Contract	Ve declare that all n - Calibration". viding incomegards damages by) we are directly occupied with					
	Name: Signature:							
	Job title: Company's seal:							
	Date:							
	Release for repair grant by VACUUBRAND (date / signature):							
	VACUUBRAND GMBH + CO KG	(va	cuubrand					

97877 Wertheim - Germany

www.vacuubrand.com



EG-Konformitätserklärung für Maschinen EC Declaration of Conformity of the Machinery Déclaration CE de conformité des machines

Hersteller / Manufacturer / Fabricant: VACUUBRAND GMBH + CO KG · Alfred-Zippe-Str. 4 · 97877 Wertheim · Germany

Hiermit erklärt der Hersteller, dass das Gerät konform ist mit den Bestimmungen der Richtlinien: Hereby the manufacturer declares that the device is in conformity with the directives: Par la présente, le fabricant déclare, que le dispositif est conforme aux directives:

2006/42/EG 2014/30/EU 2014/34/EU 2011/65/EU

Pumpstand / Pumping unit / Groupe de pompage:

Typ / Type / Type: PC 3001 VARIO^{pro} / PC 3001 TE VARIO^{pro} / PC 3001 VARIO^{pro} IK / PC 3001 VARIO^{pro} emission condenser Peltronic / PC 3001 VARIO^{pro} without emission condenser Artikelnummer / Order number / Numéro d'article: 696700, 696701, 696702, 696703, 2613943, 2613980 / 696710, 696713 / 696745 / 696735 / 696753, 696755 Seriennummer / Serial number / Numéro de série: Siehe Typenschild / See rating plate / Voir plaque signalétique

Angewandte harmonisierte Normen / Harmonized standards applied / Normes harmonisées utilisées:

DIN EN 12100:2011, DIN EN 61010-1:2011, IEC 61010-1:2010 (Ed. 3), DIN EN 1012-2:2011, DIN EN 61326-1:2013, DIN EN 1127-1:2011, DIN EN 13463-1:2009, DIN EN 50581:2013

Bevollmächtigter für die Zusammenstellung der technischen Unterlagen / Person authorized to compile the technical file / Personne autorisée à constituer le dossier technique: Dr. J. Dirscherl · VACUUBRAND GMBH + CO KG · Alfred-Zippe-Str. 4 · 97877 Wertheim · Germany

Wertheim, 24.07.2017

Ort, Datum / place, date / lieu, date

(Dr. F. Gitmans)

Geschäftsführer / Managing Director /

Gérant

(Dr. J. Dirscherl)

Technischer Leiter / Technical Director /

Directeur technique

VACUUBRAND GMBH + CO KG Alfred-Zippe-Str. 4 · 97877 Wertheim T +49 9342 808-0 · F +49 9342 808-5555 info@vacuubrand.com - www.vacuubrand.com



Certificate **TÜV**Rheinland Certificate no. CU 72113298 01 License Holder: Manufacturing Plant: VACUUBRAND GMBH + Co. KG VACUUBRAND GMBH + Co. KG Alfred-Zippe-Str. 4 Alfred-Zippe-Str. 4 97877 Wertheim 97877 Wertheim Germany Germany Test report no.: USA-JE 31183478 001 Client Reference: M. von Przychowski UL 61010-1:2004 R10.08 Tested to: CAN/CSA-C22.2 NO. 61010-1-04+GI1 (R2009) Certified Product: Diaphragm Vacuum Pump for Laboratory Use License Fee - Units Model Designation: PC 3001 y zzz; VP 2 autovac y = VARIO, basic, VARIO TE, VARIO +IK, AD VARIO z = blank, A-Z, +, - (customer specificconfigurations) Rated Voltage: AC 100-230V, 50/60Hz Rated Current: 1.6A/0.7A Protection Class: Appendix: 1, 1-2 Licensed Test mark: **Signature** Date of Issue (day/mo/yr) 22/12/2011 TÜVRheinland Dipl.-Ing. J. Engels QA Certification Officer

This certificate is only valid for pumps with the respective mark (Licensed Test mark) on the pump rating plate.



DECLARATION OF CONFORMITY - China RoHS 2

VACUUBRAND GMBH + CO KG has made reasonable efforts to ensure that hazardous materials and substances may not be used in its products.

In order to determine the concentration of hazardous substances in all homogeneous materials of the subassemblies, a "Product Conformity Assessment" (PCA) procedure was performed. As defined in GB/T 26572 the "Maximum Concentration Value" limits (MCV) apply to these restricted substances:

•	Lead (Pb):	0.1%
•	Mercury (Hg):	0.1%
•	Cadmium (Cd):	0.01%
•	Hexavalent chromium (Cr(+VI)):	0.1%
•	Polybrominated biphenlys (PBB):	0.1%
•	Polybrominated diphenyl ether (PBDE):	0.1%

Environmental Protection Use Period (EPUP)

EPUP defines the period in years during which the hazardous substances contained in electrical and electronic products will not leak or mutate under normal operating conditions. During normal use by the user such electrical and electronic products will not result in serious environmental pollution, cause serious bodily injury or damage to the user's assets.



The environmental Protection Use Period for VACUUBRAND products is 40 years.

此表格是按照SJ/T 11363-2006中规定所制定的。

This table is created according to SJ/T 11363-2006.

MATERIAL CONTENT DECLARATION FOR VACUUBRAND PRODUCTS									
有毒有害物质或元素 Hazardous substances									
部件名称	铅	汞	镉	六价铬	多溴联 苯	多溴二 苯醚	环保期限标 识		
Part name	Pb	Hg	Cd	Cr(+VI)	PBB	PBDE	EPUP		
包装 Packaging	0	О	0	0	0	0			
塑料外壳 / 组件 Plastic housing / parts	0	0	0	0	0	0			
真空油 Vacuum oil	0	0	0	0	0	0	(e)		
电池 Battery	0	0	0	0	0	0			
玻璃 Glass	0	0	0	0	0	0			
电子电气组件 Electrical and electronic parts	Х	Х	Х	0	0	0			
控制器 / 测量设备 Controller / measuring device	X	0	X	0	0	0			
金属外壳 / 组件 Metal housing / parts	X	0	0	0	0	0	407		
电机 Motor	Х	0	0	0	0	0			
配件 Accessories	Х	0	0	0	0	0			



注释: 此表格适用于所有产品。以上列出的元件或组件不一定都属于所附产品的组成。

Note: Table applies to all products. Some of the components or parts listed above may not be part of the enclosed product.

O: 表示该有毒有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。

O: Indicates that the above mentioned hazardous substance contained in all homogeneous materials of the part is below the required limit as defined in GB/T 26572.

X: 表示该有毒有害物质至少在该部件某一均质材料中的含量超出GB/T 26572规定的限量要求。

X: Indicates that the above mentioned hazardous substance contained in at least one of the homogeneous materials of this part is above the required limit as defined in GB/T 26572.

除上表所示信息外,还需声明的是,这些部件并非是有意用铅(Pb)、 汞 (Hg)、铬(Cd)、六价铬 (Cr(+VI))、多溴联苯(PBB)或多溴二苯醚(PBDE)来制造的。

Apart from the disclosures in the above table, the subassemblies are not intentionally manufactured or formulated with lead (Pb), mercury (Hg), cadmium (Cd), hexavalent chromium (Cr+VI), polybrominated biphenyls (PBB), and polybrominated diphenyl ethers (PBDE).

Products manufactured by VACUUBRAND may enter into further devices (e.g., rotary evaporator) or can be used together with other appliances (e.g., usage as booster pumps). With these products and appliances in particular, please note the EFUP labeled on these products. VACUUBRAND will not take responsibility for the EFUP of those products and appliances.

Place. date: Wertheim, 04/24/2017

(Dr. F. Gitmans) (Dr. J. Dirscherl)

Managing Director Technical Director

VACUUBRAND GMBH + CO KG

Alfred-Zippe-Str. 4
97877 Wertheim

Germany

Tel.: +49 9342 808-0
+49 9342 808-5555

E-Mail: info@vacuubrand.com
www.vacuubrand.com
www.vacuubrand.com

Disclaimer: Our technical literature is only intended to inform our customer. The applicability of general empirical values and results obtained under lab conditions to your specific operations depends on a number of factors beyond our control. It is, therefore, strictly the users' responsibility to very carefully check the application of these data to their specific requirements. No claims arising from the information provided in this literature will, consequently, be entertained.



Alfred-Zippe-Str. 4 · 97877 Wertheim / Germany T +49 9342 808-0 · F +49 9342 808-5555 info@vacuubrand.com · www.vacuubrand.com

VACUUBRAND GMBH + CO KG

- Technology for Vacuum Systems - © 2017 VACUUBRAND GMBH + CO KG Printed in Germany

Manual-no.: 999166 / 07/24/2017