



Pull-off Testers DY-206

Automated pull-off tester ideally suited for low strength applications



Accuracy

The ideal calibration accuracy EN ISO 7500-1 Class 2 for low strength applications such as testing adhesive strength of mortars and renders



Performance

A comprehensive range of test discs plus adjustable foot configuration to cover a wide variety of applications with complete reporting



Ease of use

Easy to operate, even on overhead walls to add to a simple programming process of key parameters and a fully automated test



Processing Unit / Sensor

Working Range	0.3 to 3.1 MPa (44 to 443 psi)
Tensile force (50 mm test disc)	0.6 to 6 kN (135 to 1349 lbf)
Maximum Stroke	5 mm
Maximum Pulling Speed	4.65 mm/min (0.183 inch/min)
Instrument Firmware	Maximum load Actual load rate Test duration Complete report of the test Failure mode reporting Full data review on instrument
PC Software	DY-2 Link with a live view of actual load rate graph
Memory	100 measurements
Connections	USB to PC and for charging
Calibration Accuracy	EN ISO 7500-1 Class 2 ($\pm 2\%$ from 20 % of the maximum force)
Battery Capacity	1500 mAh, 3.7V (min. 80 measurements)
Weight	4.5 kg
Applications:	<ul style="list-style-type: none">✓ Adhesive strength of mortars and renders✓ Adhesive strength of tiles✓ Bond strength of coatings and overlays✓ Tensile strength in concrete renovation

SWISS  MADE

Present in +100 countries, we serve inspectors and engineers all over the world with the most comprehensive range of InspectionTech solutions, combining intuitive software and Swiss-manufactured sensors.

www.screeningeagle.com

Request a quote