


Agilent Multi-Gas CrossLab Sniffer Leak Detector



The Agilent Multi-Gas CrossLab Sniffer Leak Detector is designed to detect leaks of noncorrosive gases, including mixtures of gases.

Mini-sized portable multi-gas sniffer, high sensitivity, and low cost

The Multi-Gas CrossLab Sniffer leak detector is the latest mini-sized portable sniffer from Agilent's Vacuum Products Division. This sniffer leak detector provides an industrial level of sensitivity and responsiveness for the various gas types, such as helium, hydrogen, argon and nitrogen.

Features

- High sensitivity TCD sensor
- Palm-sized instrument
- Lightweight ergonomic design with kickstand
- Excellent response and zeroing time
- Easy-read OLED display
- Audible leak rate alarm/beep at 49.9dB
- Firmware upgradable via USB for newly added features and updates
- Battery and USB powered

The multi-gas sniffer leak detector is perfect for verifying and troubleshooting gas delivery systems thus avoiding costly leaks and safety concerns. It is also a perfect manufacturing tool for leak checking stations for offline leak location and repair.

The multi-gas leak detector provides a low-cost solution for those sniffing applications that don't require a quantifiable leak rate verification.

The instrument's high sensitivity TCD sensor is capable of distinguishing gases with higher thermal conductivity than air such as hydrogen and helium and gases with lower thermal conductivity than air like argon and xenon. Therefore, a greater difference in thermal conductivities results in greater sensitivity and ability to detect very small leaks.

Detection Mode of Operation



Table 1. Thermal conductivity of common gases at 0°C, 1 atm.

| Gas | Thermal Conductivity (mW/M K) |
|----------------|-------------------------------|
| Hydrogen | 168.2 |
| Helium | 142.2 |
| Neon | 46.5 |
| Methane | 30.2 |
| Oxygen | 26.7 |
| Air* | 24.1 |
| Nitrogen | 24.0 |
| Ethane | 18.0 |
| Ethylene | 16.4 |
| Argon | 16.3 |
| Carbon Dioxide | 14.5 |
| Krypton | 8.7 |
| Xenon | 5.2 |

^{*} Reference gas is not detectable.

Filled bar. Gas leak for gases with higher thermal conductivity than air.



Empty bar. Gas leak for gases with lower thermal conductivity than air.



Table 2. Calculated minimum detectable leak rate for selected gases and the style of bar used as a gas level indicator.

| Gas | Minimum Detectable Leak Rate (mbar I/sec) | Bar Type used as a Gas Level Indicator |
|----------------|--|---|
| Hydrogen | 4.2E-5 | Filled bar |
| Helium | 5.1E-5 | Filled bar |
| Methane | 2.3E-4 | Filled bar |
| Nitrogen | 6.8E-3 | Empty bar |
| Argon | 5.1E-4 | Empty bar |
| Carbon Dioxide | 5.1E-4 | Empty bar |

Technical Specifications

| Sensitivity | Helium 5.1E-5 mbar l/s Hydrogen 4.3E-5 mbar l/s |
|-----------------------------|--|
| Response Time | <2 seconds |
| Zeroing Time | <1.5 seconds |
| Audible Leak Rate Alarm | 49.9 dB |
| OLED Display | 128x64 monochrome w/16 grayscales |
| Power | Three AA batteries (alkaline) or USB power |
| Operating Temperature Range | 0 to 45°C (noncondensing) |
| Storage Temperature | -15 to 50°C |
| Dimensions | 201mm x 88mm x 48mm |
| Weight | 420g |

Ordering Information

| Description | Part Number | |
|---|-------------|--|
| Multi-Gas CrossLab Sniffer Leak Detector | G8613A | |
| Replacement Leak Detector Cartridge only | G6694A | |
| Leak Detector Probe Mesh Filter | G6694-60005 | |

Contact information

Americas

Agilent Technologies 121 Hartwell Avenue, Lexington, MA 02421 USA Toll free: +1 800 882 7426 vpl-customercare@agilent.com

Europe, Middle East, Africa, India

Agilent Technologies Italia SpA Via F.Ili Varian 54, 10040 Leini (Torino), Italy Tel: +39 011 9979 111 Toll free: 00 800 234 234 00 vpt-customercare@agilent.com

China

Beijing Office Agilent Technologies (China) Co. Ltd. No.3, Wang Jing Bei Lu, Chao Yang District, Beijing, 100102, China Toll free: 800 820 6778 Contacts.vacuum@agilent.com

For more information, please contact your Agilent representative or visit www.agilent.com/chem/vacuum where you can chat live with a vacuum expert.

