

# Technical Description ClimeECO C4-340



# Contents.

	Page
Highlights at a glance	3
Standards	4
Performance data	5
Temperature tests	5
Climate tests	5
Heat compensation.	6
Humidity diagram	6
Technical Data	7
Dimensions and weights.	7
Technical data for installation	7
Installation drawing	8
Our basic equipment	9
Technical Details	11
General Statements	12



Quotation Number: XXXXXXXX

# Highlights at a glance.

- Functional all-rounder for climatic performance, function and aging tests in manufacutirng, storage, transport and use.
- Economic equipment appropriate for common testing norms
- Web-based 7" color touch screen with simple menu-driven user interface
- Intelligent airflow for high accuracy at various loads, air-cooled refrigeration system
- Specimen protection against condensation and over-tempering
- Foul diagnosis system for maintenance and repair, 1 year of warranty
- Uncomplicated quoting process and fast delivery due to standard design without modifications

ClimeEco C4-340 without window ClimeEco C4-340 with window

Ordering code: 67610949 Ordering code: 67610950



Quotation Number: XXXXXXXX

## Standards.

## Low temperature test

- IEC 60068-2-1, Test A
- ISO 16750-4, Low temperature
- MIL-STD-810 G, Meth. 502.5
- JESD22-A119

# High temperature tests

- IEC 60068-2-2, Test B
- ISO 16750-4, High temperature
- MIL-STD-202 G, Meth. 108A
- MIL-STD-810 G, Meth. 501.5
- MIL-STD-883 J, Meth. 1008.2
- JESD22-A103D

# Alternating temperature test

- IEC 60068-2-14, Test Nb
- ISO 16750-4, Temp. steps
- ISO 16750-4, Temp. Cycling

## **Constant climate test**

- IEC 60068-2-67
- IEC 60068-2-78
- ISO 16750-4, Damp heat steady
- MIL-STD-202 G, Meth. 103B

# Alternating climate test

• IEC 60068-2-30, Test Db, Var.2

We reserve the right to make any technical changes without prior notice.

The temperature values specified in the standards (severity levels) are limited by the highest and lowest test space temperature. The choice of the appropriate test system depends on the temperature change rates during alternating tests. The requirements are met if the test system capacity is large enough to compensate for the influence of the specimen and its heat dissipation in the relevant capacity range. Please contact us to test the feasibility with your test specimen.

The reference point for test values and tolerance specifications is the middle of the test space. Verifying documentation for individual test values is optionally available at additional cost.

Your standard is not listed? Contact us!



Quotation Number: XXXXXXXX

# Performance data.

# Temperature tests.

Temperature range -40 °C to +180 °C

Average temperature rate Heating: 3.2 K/min of change according to Cooling: 3.5 K/min

IEC 60068-3-5

Temperature deviation (according to IEC 60068-3-5)

In time  $\pm 0.1$  K to  $\pm 0.5$  K In space  $\pm 0.5$  K to  $\pm 2.0$  K

Heat compensation at

+20 °C 2000 W -20 °C 750 W

Temperature calibration +23 °C and +80 °C values are measured at

## Climate tests.

Humidity range 10 % r.H to 98% r.H

Climatic Mode +10 °C to +95 °C

Dew point range -3 °C to +92 °C

Temperature deviation according to IEC 60068-3-5

In time  $\pm 0.1$  K to  $\pm 0.3$  K In space  $\pm 0.5$  K to  $\pm 1.0$  K

Humidity deviation in time  $\pm 1 \%$  r.H to  $\pm 3 \%$  r.H.

Humidity water consumption Max. 2l/24h

Heat compensation 400 W


Temperature calibration  $+23 \,^{\circ}\text{C} \, 50 \,^{\circ}\text{m} \, \text{r.H}$  and  $+95 \,^{\circ}\text{C} \, 50 \,^{\circ}\text{m} \, \text{r.H}$  values are measured at  $^{1}$ 

We reserve the right to make any technical changes without prior notice.




Quotation Number: XXXXXXXX

# Heat compensation.



# Humidity diagram.



- A: Test space temperature
- **B**: Relative humidity
- 1: Standard climate range for continuous operation.
- 2: The standard climate range for discontinuous operation only (dew points ranging from +4 °C to -3 °C).

We reserve the right to make any technical changes without prior notice.



# **Technical Data.**

## Dimensions and weights.

Test space volume 335 l

Test space dimensions, H x W x D 750 mm x 580 mm x 765 mm

Exterior housing dimensions, H x W x D 1785 mm x 870 mm x 1814 mm

Required transportation clearance, H x W x D 1955 mm x 1014 mm x 1844 mm

Window (heated)<sup>(option)</sup>, H x W 600 mm x 450 mm

Weight approx. 500 kg net

## Technical data for installation.

Operating conditions Ambient temperature: +10 °C to +35 °C;

max. rel. air humidity 75 % r.H.

Sound pressure level Approx. 63 dB(A) according to DIN 45 635,

part 1, accuracy class 2

Humidification water (C-models only) Fully demineralized water, pH value of 6-7,

conductivity max. 20µS/cm

Drain for condensate and Di = 12 mm hose connection,

cleaning water back-pressure free for condensation water

**Electrical:** 

Nominal voltage 3/N/PE AC 400V  $\pm 10\%$  50Hz


Nominal power 4.79 kW
Nominal current 12.3 A
Connection cable Approx. 3 m
Fuse protection 16 A slow
Protection class IP 20








Quotation Number: XXXXXXXX

# Installation drawing.









- 1 Master switch panel
- 2 7" control unit
- 3 Connector panel
- 4 Connection for overflow/ condensate drain
- 5 Electrical connection, cable length approx. 3.5 m
- 6 Door with window (option)
- 8 Cooling water supply (option)
- 9 Cooling water return (option)
- 10 Connection for demineralised water
- 14 Compressed air connection (option)

We reserve the right to make any technical changes without prior notice.



Quotation Number: XXXXXXXX

# Our basic equipment.

Casing Zinc-coated steel powder-coated

colour: RAL 9002, grey-white

Door One-hand operation, lockable,

hinged on the left hand side

Test space Polished stainless steel - grade 1.4301

max. load of test space floor 60 kg (surface load),

a maximum of 8 shelves is possible,

max. load for each shelf: 30 kg (surface load),

max. total load 80 kg,

total load shelf and test space floor is max. 140 kg

Insertion shelf 1 insertion shelf made of stainless steel

a maximum of 8 shelves is possible

max. load for each shelf 30 kg (surface load)

max. total load 80 kg

Entry port 2 Entry port  $\varnothing$  50 mm l. h. side,  $\varnothing$  125 mm r. h. side

Option: R2..n, L2..n, D1 in ceiling

Refrigeration unit<sup>1</sup> Air-cooled refrigeration system with

Refrigerant<sup>2</sup> Chloride-free refrigerant R449A

R449A, GWP: 1397, filling quantity: 3 kg

CO<sub>2</sub> equivalent: 4.2 t

We reserve the right to make any technical changes without prior notice.

<sup>1</sup> The product contains fluorinated greenhouse gases.

<sup>&</sup>lt;sup>2</sup> (EU) directive no. 517/2014 specifies an obligation for stationary refrigeration and air conditioning units with a CO2 equivalent of 5 to 50 t to be checked for leaks at least annually and an equipment logbook to be kept; units with a leak detection system must be checked every 24 months. We can carry out these tasks for you in our capacity as an expert partner. We would be glad to advise you on installing a leak detection system.



Date: XX.XX.XXXX

9 / 13

## Regulation and control (S!MPAC®)

**WEB**Season® Web based measuring and control system with

I/O unit and **WEB**Season®-software

Operating/programming and monitoring unit

with 18 cm (7") web panel

Control Highly efficient 32 bit control and monitoring

system S!MPAC®

Program memory Max. 100 programs

Program controller Start parameters for programs: immediately,

delayed, real time, pause

PID Controller Special control algorithms defined according to test tasks

Segments Max. 100 per Programm

Loops 250 (nested)

Programm cycles Max. 9999

Passwort protection Two levels to prevent accidental settings

Limit value monitoring system For temperature and humidity

Diagnostic system

TCP/IP Ethernet interface

For information on operating times and possible operating failures

Connection with customer's computer (e.g. Notebook-operating panel or SIMPATI) or for 3<sup>rd</sup> party networking for communication via

software package SIMPATI

Connection to building control Profibus or Interbus via Gateway, other additional

systems upon request

Customer protocols SimServ (to control the temperature test

chamber via the ethernet interface)



We reserve the right to make any technical changes without prior notice.



Quotation Number: XXXXXXXX

## **Technical Details.**

#### Construction

The climate test cabinets by WVC are supplied ready for connection. Compact design means a minimum of space is required. Five test cabinets with a volume from 190 to 1540 I are available. All cabinets are designed to be free-standing in one location. The machine section incorporating the refrigeration unit, the water storage tank and the water pump is located below the test chamber. The swing-out switch cabinet is located on the rear of the cabinet. The operating elements and the main switch are located on the right side of the cabinet.

## **Exterior Housing**

The exterior housing of the unit is made from lightweight corrosion-resistant, selfsupporting, galvanized sheet-steel and lacquered in two colors (RAL 7016 anthracite and RAL 9002 grey-white).

The environmental-friendly insulation between test chamber and exterior housing guarantees best insulation values and thus lowest possible operating costs.

#### **Test Chamber**

The test chamber consists of a stainless-steel container and is welded vapor-tight. The test chamber is easy to clean thanks to special welding, smooth surfaces, rounded edges and shelf supports. The rear test chamber wall incorporates an air duct with built-in humidifier tub (C-models), built-in heat exchanger, electric heaters and a recirculating air fan. Air guidance via baffle plates in the test chamber floor and ceiling produces optimum ambient air and temperature distribution.

## **Test Chamber Door**

The test chamber is completely sealed by a door that is hinged on the left. The door opens fully for easy access and is equipped with high quality insulation. An optimum seal is guaranteed by special profile seals and a selftightening locking mechanism which is operable with one hand.

#### **Access Ports**

All cabinets have two access ports (approx. 50 and 125 mm diameter) made of low thermal conductivity material. The ports are in the left and right side walls and can be used for measuring and control wires, other supply connections or accessories. If not required, these ports are closed with rubber plugs supplied as standard.

## **Temperature and Humidity Conditioning**

The large axial fan with exterior drive motor draws the air out of the space. This recirculating air then passes a fin-type heat exchanger, which cools the air, if necessary. The special design of the refrigerating system avoids unintended condensation precipitation at the heat exchanger during climatic operation and guarantees highest temperature and humidity constancies in time. An electrical heater, installed in front of the heat exchanger in air direction, is heating-up the recirculating air.

An innovative humidification system allows a high relative humidity even with a heat load (C-models).

## **Psychometric Humidity Measuring (C-models only)**

The humidity of the test space air is measured according to the internationally valid psychrometric measuring principle with two resistance thermometers Pt 100 as per



**Quotation Number: XXXXXXXX** 

DIN IEC 751. Dry and wet bulb sensors are arranged next to each other in the recirculating air flow. Depending on the climate the material of the wet bulb sensor is humidified. The life time is increased considerably due to a self-cleaning mechanism!

#### **Protection System against Condensation**

The protection system consists of a dehumidifying evaporator which prevents condensation forming on the specimens as they heat-up after tests at low temperatures.

The protection system's operating range is -40 to +60 °C.

The protection system against condensation is activated by a digital switch channel. It is possible to switch on the protection system manually or to integrate it into a program.

## Dew Point Extension from +4 °C to -3 °C (C-models only)

In this working range the humidity constancy in time is  $< \pm 5$  % r.h. The extended working range can be operated at intervals. The max. operation time without defrosting is approx. 24 hrs.

## **Specimen Protection**

In addition to the programmable limit value monitoring system of the SIMPAC, the climate test cabinet is equipped with a high and low temperature limit controller which can be adjusted digitally (specimen protection with separate sensor) according to EN 60519-2 (1993). The signal is indicated visually and acoustically. A potential-free contact to switch off power supplies is available to the customer.

### **Permanently Memorized Overheating Safety Thermostat**

A steady state overheating safety thermostat is installed that automatically switches off the heater if the test chamber's maximum temperature range is exceeded.

#### **Power Supply**

Each functional circuit is equipped with its own safety device, which, in the event of trouble, turns off the affected circuit or the entire cabinet. The nature of the trouble is visually displayed. Wiring and electrics are governed by the latest technology and strictly conform to safety regulations for electrical installations and materials, as well as to relevant VDE regulations. The test cabinets are standard-wise equipped with a lockable main switch according to VDE.



Quotation Number: XXXXXXXX

## **General Statements.**

In the constant effort to improve our product, we reserve the right to make construction or design changes without prior notice or obligation.

Please note that for installation of the climate test cabinet (for components which jut out, such as: hinges, locks, etc.) the clearance requirements indicated in the technical data must be observed.

The performance data indicated were determined with empty test space and refer to an appliance without additional ports or devices, which represent a thermal load with an ambient temperature of max. +25 °C and with water-cooled refrigeration units (option) to a water temperature of approx. +28 °C.

The cabinet is designed to be installed in normal rooms. The max. admissible ambient temperature for storage and installation is +55 °C (+131 °F).

The admissible ambient temperature for operation of the cabinet is between +10 °C and +35 °C (+50 °F and +95 °F).

Performance data cannot be guaranteed in ambient conditions other than those stated.

Accuracy rates are proven in the test space center, in steady state, without specimens, without radiation and without additional equipment in the test space. The cooling down rate stated refers to the temperature range without controlled humidity.

In case of outgassing or pollution caused by the specimen we recommend regular maintenance of the measuring system. Please keep in mind that outgassing of specimens and connection lines might cause corrosion of components. Corrosive gasses might escape among others from chip boards, cardboard boxes and bandaging materials.

If outgassing is to be expected, we recommend an optional ventilation of the test space with a purge air volume. If outgassing or pollution is expected, we also recommend a regular maintenance of the measuring system.

Measures to be taken regarding a necessary combination with other units have to be approved by the local supervising authorities. The relevant costs are not included in our quotation.

Please note that the sealing material and cable insulation used in our test units and systems contains silicone. If this is a problem for you, please contact us.

The concept and design of the test units and systems are in accordance with the relative safety requirements and regulations of the EC-standards directive for machinery 2006/42/EG,EMC Directive 2014/30/EG and the EC Directive for Pressurized Equipment 2014/68/EG 97/23/EG. The above regulations are adhered to when modifications or extensions are performed on site. The EMC test and the data on the noise emission are in accordance with EN 61 000-3 and EN 61 000-6-2.



Quotation Number: XXXXXXXX