

Datasheet

Half mask 620S



With Safety.

BR-Article-No.: 913510
Article-Name: Half mask 620 S
Article-Denomination: Half mask EN 140 with standard thread connector acc. EN 148-1
Kind of Article: Face piece acc. DIN EN 140 for respiratory protection (Personal protection equipment)



Use: - Connected with a breathing filter as filtering device
- Connected with a compressed air line breathing apparatus as an insulated breathing protection device

Description: Mask body of silicone rubber covering mouth, nose and chin, standard thread connector piece with inhalation valve, two lateral exhalation valves, adjustable roller banding fixed at the exhalation valve housings

Function: The air drawn in passes the inhalation valve. The exhalation air flows through two exhalation valves directly to the ambient air.

Materials:	Mask body	silicone rubber
	Connector piece	Polyethylene
	Harness	silicone rubber
	Inhalation valve seat with gasket	rubber
	Inhalation valve membrane	silicone rubber
	Exhalation valve housing and screw ring	Polyamide
	Exhalation valve membrane	rubber
	Exhalation valve cover	Polyethylene
	Fixing clamp	Polyamide
	Sweat absorbing sponge	Viscose

Measurements: approx. 105 x 130 x 120 mm (box)

Weight: approx. 180 grams

Marking: **620 S** **BAKIKOS/BR-Logo** **CE 0158** **EN 140**

Storage: Room temperature protected against heat, cold and humidity

Advice: Follow instructions for use

Revision 09.2016 – Errors and omissions excepted. All data are non-binding guide values.

BartelsRieger Atemschutztechnik GmbH

Richard-Byrd-Straße 23 | 50829 Cologne | Phone +49 (0)221 59777-0 | mail@bartels-rieger.de | www.bartels-rieger.de

Ust.-IdNr. DE 815603312 | St.-Nr. 217/5811/1510 | Reg.-Gericht Köln | HRB 54098 | Managing Director: Tobias Rutt